

# **System Manual**

# **Energy Storage System**

PowerStack-ST455kWh-110kW-4h



# **All Rights Reserved**

#### **All Rights Reserved**

No part of this document can be reproduced in any form or by any means without the prior written permission of Sungrow Power Supply Co., Ltd (hereinafter "SUNGROW").

#### **Trademarks**

**SUNGROW** and other SUNGROW trademarks used in this manual are owned by SUNGROW.

All other trademarks or registered trademarks mentioned in this manual are owned by their respective owners.

#### **Software Licenses**

- It is prohibited to use data contained in firmware or software developed by SUNGROW, in part or in full, for commercial purposes by any means.
- It is prohibited to perform reverse engineering, cracking, or any other operations that compromise the original program design of the software developed by SUNGROW.

# **About This Manual**

This manual gives an introduction to the transport and storage, mounting, electrical connection, powering on/off, troubleshooting, and maintenance of the Energy Storage System ("ESS").

#### **Target Group**

This manual is intended for operators of the energy storage plant and qualified technical persons. The installation and operation must be performed only by qualified technical persons, who must:

- Have received professional training
- Have read through this manual carefully and have a good understanding of the relevant safety instructions
- Be familiar with applicable local standards and the relevant safety code for electrical system

#### **How to Use This Manual**

Read the manual and other related documents before performing any operation on the product. Documents must be properly kept and be available at all times.

To increase customer satisfaction, the product and its manual will be updated and improved constantly. If the manual you have received is slightly inconsistent with the real product, it is probably owed to a product update. In such a case, the real product should take precedence. You can find the latest manual at **support.sungrowpower.com**, or reach your sales for the manual

The figures in this manual are for reference only. The real product may differ.

#### Symbols in the Manual

To ensure the safety of life and property for users when using the product and to improve the efficiency of product use, the manual provides relevant safety information, which are highlighted by the following symbols.

Symbols that may appear in this manual are listed below. Please read carefully for better use of this manual.

#### **▲** DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

#### **M** WARNING

Indicates a moderately hazardous situation which, if not avoided, will result in death or serious injury.

#### **A** CAUTION

Indicates a slightly hazardous situation which, if not avoided, may result in minor or moderate injury.

#### NOTICE

Indicates a potential hazard which, if not avoided, will result in device malfunction or property damage.



Indicates supplementary information, emphasis on specific points, or tips related to the use of the product that might help to solve your problems or save your time.

#### Signs on the Product

Observe the safety signs on the product at all times, which include:

Sign	Explanation
	Hot surface! Do not touch. Otherwise, it may cause personal injuries.
$\triangle$	Disconnect the equipment from all the external power sources before maintenance!
A	High voltages inside! Touching it may result in an electric shock.
	Danger of death due to high voltages!
	After the equipment is disconnected from the external power source,
5min	wait at least 5 minutes before touching any of its internal conductive
	parts.
	Beware of heavy weights! Lifting the heavy object directly may cause
	back injury. Please lift it with the assistance of proper tools.
	Beware of explosion.
	Beware of corrosion.
	Do not dispose of it together with household waste.
	No fires.
+	A medical facility should be set up nearby.
<b>©+</b>	If it gets in your eyes, flush your eyes immediately with running water
<b>T</b>	or saline, and seek medical advice in time.

Sign	Explanation
	Protective earthing (PE) terminal. This terminal should be connected
	for reliable grounding, to ensure the safety of the operator.
	Read the instructions before performing any operation on the
	product.
	Wear safety goggles.

# Contents

ΑI	ll Rights Reserved	
ΑŁ	bout This Manual	
1	Safety Precautions	1
	1.1 Personnel Requirements	1
	1.2 Electrical Safety	1
	1.3 Battery Safety	2
	1.4 Hoisting and Transportation	5
	1.5 Installation and Wiring	5
	1.6 Operation and Maintenance	5
	1.7 Product Disposal	6
2	Product Description	7
	2.1 Product Overview	7
	2.2 External Design	8
	2.2.1 ESS External Design	8
	2.2.2 Mechanical Parameters	9
	2.2.3 Ventilation Design	10
	2.3 Internal Design	11
	2.3.1 Internal Components	11
	2.3.2 PCS (SC110CX)	12
	2.3.3 Battery Power Supply Panel (BSP)	14
	2.3.4 Battery	15
	2.3.5 EMS Controller (Optional)	18
	2.4 Transformer Cabinet	20
	2.4.1 Cabinet Appearance	20
	2.4.2 Mechanical Parameters	21
	2.4.3 Internal Equipment	22
3	Transport and Storage	24
	3.1 Precautions	24
	3.2 Transport Methods	24
	3.3 Transport Requirements	24
	3.4 Storage Requirements	25

4	Mechanical Installation	27
	4.1 Inspection Before Installation	27
	4.1.1 Deliverables Inspection	27
	4.1.2 Equipment Inspection	27
	4.2 Installation Environment Requirements	27
	4.2.1 Installation Site Requirement	27
	4.2.2 Foundation Requirements	28
	4.2.3 Installation Space Requirements	29
	4.3 Handle with Forklift	35
	4.4 Hoisting	37
	4.4.1 Precautions	37
	4.4.2 Hoisting System	39
	4.4.3 Hoisting Procedure	40
	4.5 Cabinets Fixing	41
5	Electrical Connection	43
	5.1 Precautions	43
	5.2 Electrical Connection Overview	43
	5.3 Preparation Before Wiring	46
	5.3.1 Prepare Installation Tools	46
	5.3.2 Open Cabinet Door	46
	5.3.3 Prepare Cables	47
	5.3.4 Copper Wire Connection	49
	5.3.5 Aluminum Wire Connection	49
	5.3.6 Cable Inlet Design	50
	5.4 Ground Connection	51
	5.5 AC Connection	54
	5.5.1 Safety Precautions	54
	5.5.2 Overview of the Wiring Area	55
	5.5.3 ESS AC Output Wiring	55
	5.5.4 LVS250UD-Load Connection Steps	56
	5.6 Auxiliary Power Supply Wiring	57
	5.7 EMS/LC/FSS External Power Supply Wiring	58
	5.8 Fault Dry Contact Signal Connection (Off-grid)	60
	5.9 Ethernet Communication	61
	5.10 Post-wiring Work	63
6	Battery Connection	64
	6.1 Precautions	64

	6.2 Battery Wiring	65
7 F	Powering up and Shutdown	69
	7.1 Powering up	69
	7.1.1 Inspection Before Powering up	69
	7.1.2 Powering on Steps	69
	7.2 Shutdown	70
	7.2.1 Planned Shutdown	70
	7.2.2 Emergency Shutdown	71
8 F	Fire Suppression	72
	8.1 General Rules	72
	8.2 Fire Suppression System	72
	8.3 Device Introduction	73
	8.3.1 Fire Detection and Alarm System	73
	8.3.2 Fire Extinguishing System	74
	8.3.3 Backup Protection System	75
9 -	Troubleshooting	77
10	Routine Maintenance	78
	10.1 Precautions Before Maintenance	78
	10.2 Liquid Cooling System Maintenance	78
	10.3 Container Maintenance	79
	10.3.1 Appearance Repair	79
	10.3.1.1 Detergent Cleaning	80
	10.3.1.2 Finish Paint Repair	80
	10.3.1.3 Double-Layer Paint Repair	83
	10.3.2 Checking Door Locks and Hinges	86
	10.3.3 Checking Sealing Strips	86
	10.4 Battery Maintenance	86
	10.4.1 Maintenance Precautions	86
	10.4.2 Maintenance	88
	10.5 Coolant Replacement	89
11	Appendix	92
	11.1 Abbreviations	92
	11.2 Technical Data	93
	11.3 Tightening Torques	95
	11.4 Quality Assurance	95
	11.5 Contact Information	96

# 1 Safety Precautions

# 1.1 Personnel Requirements

The hoisting, transportation, installation, wiring, operation, and maintenance of the equipment must be carried out by qualified electrical technicians in accordance with local regulations. Qualified technicians must:

- Have certain electrical wiring, electronic, and mechanical expertise, and be familiar with electrical and mechanical schematics.
- Be familiar with the composition and working principles of the equipment and its upstream and downstream equipment.
- Have received professional training in the installation and commissioning of electrical equipment.
- Be able to respond quickly and effectively to dangers or emergencies that may occur during the process of installation and commissioning.
- Be familiar with applicable local standards and specifications of the country/region where the project is located.

# 1.2 Electrical Safety

#### **▲** DANGER

- Touching the power grid or the contact points and terminals in the devices connected to the power grid may lead to electric shock!
- The battery side or the power grid side may generate voltage. Always use a standard voltmeter to ensure that there is no voltage before touching.

#### **▲** DANGER

- Lethal voltages are present inside the product!
- · Note and observe the warnings on the product.
- Respect all safety precautions listed in this manual and other pertinent documents.
- Respect the protection requirements and precautions of the lithium battery.

1 Safety Precautions System Manual

#### **A** DANGER

 Electricity may still exist in the battery when the power supply of the equipment is disconnected. Wait 10 minutes to ensure the equipment is completely voltage-free before any operation.

#### **⚠** WARNING

 All hoisting, transportation, installation, wiring, operation, and maintenance must be carried out complying with the relevant codes and regulations of the country where the project is located.

#### **⚠** WARNING

 Always use the product in accordance with the requirements described in this manual. Otherwise, equipment damage may occur.

#### NOTICE

To prevent misuse or accidents caused by unrelated personnel, observe the following precautions:

- Post prominent warning signs around the product to prevent accidents caused by false switching.
- · Place necessary warning signs or barriers near the product..

# 1.3 Battery Safety

#### **▲** WARNING

Do not leave the product in a low voltage or low SOC (State Of Charge) condition for a long period of time. Loss of capacity due to the following conditions is not covered by the warranty.

- Battery discharge cell voltage is below 2.7V for 120 consecutive hours.
- Any cell cluster SOC is 0% for 120 consecutive hours.
- Battery discharge cell voltage ≤2V.

System Manual 1 Safety Precautions

#### **▲** WARNING

Over or under voltage fault & alarm (detailed information can be found in the "Communication protocol→BSC200 Info-3x table→CMU (Battery Cluster Management Unit) fault word and CMU alarm word").

- Fault: "Cell over voltage fault", "Cell under voltage fault", "Total over voltage fault", "Total under voltage fault".
- Alarm: "Cell over voltage alarm", "Cell under voltage alarm", "Total over voltage alarm".

End users must assign a high priority to above listed faults and alarms reported by the SUNGROW LC (Local Controller). When an alarm or fault is triggered, the user interface should prominently highlight these issues. Furthermore, end users should promptly contact SUNGROW for timely resolution to prevent battery warranty loss due to over-discharge or overcharge.

#### NOTICE

- In order to avoid triggering the warranty expiration condition, when the "Cell Under-voltage Fault" or "Cell Over-voltage Fault" is triggered, the user must contact the local team of SUNGROW within 24 hours and follow the requirements of SUNGROW to carry out the next operation.
- If the system is configured with the "Active power up" function, When the battery container minimum rack SOC reaches the threshold for this function (the threshold can be set from 0 to the lower SOC protection value, and the threshold does not exceed 5% SOC), the system will charge the battery with low power until the SOC reaches a safe threshold (5% SOC) automatically, The recharging power can be set within the range of 100 kW to 150 kW. During Active power up, when the EMS (Energy Management System) issues a charging instruction, the LC controller will prioritize the EMS charging instruction. When the EMS issues a discharging instruction, the LC controller will respond according to the specific system SOC value. SUNGROW will enable this function by default when the device is shipped from the factory, In order to minimize the risk of undervoltage of the battery that may void the warranty, SUNGROW recommends that users do not turn off the "Active power up" function.

1 Safety Precautions System Manual

#### **NOTICE**

 If the system will not be in operation for an extended period (7 days or more), it's recommended to increase the SOC lower limit protection value to above 10% SOC. Additionally, it is important to regularly monitor the system's SOC to avoid the risk of over discharge which will cause warranty expiration.

- During maintenance or shutdown, if the SOC of any battery cluster is 0%, the SOC needs to be charged to 15% and above within 120 hours.
- If the SOC of any battery cluster is 0% during operation, the SOC needs to be charged to 5% and above within 2 hours. Or when the SOC reaches 0%, a command can be issued by the host computer EMS to change the system mode to recharge mode.

For safe use of the product, the technician should carefully read and strictly observe the safety requirements. SUNGROW shall not be liable for product functional abnormality, component damage, personal safety accident, property loss, or other damage caused by the following reasons:

- Batteries are not charged as required, thus resulting in battery capacity loss or irreversible damage.
- Batteries are damaged or dropped, or have leaked, due to improper operations or failure to perform operations as required.
- Batteries are damaged due to overdischarge as they have not been powered on in time.
- Batteries are damaged due to the use of improper equipment for charging and discharging.
- Batteries are frequently overdischarged due to improper maintenance; battery capacity is incorrectly expanded; or batteries have not been fully charged for a long time.
- Battery operation parameters are not correctly set.
- Batteries are damaged because their operating environment does not meet the requirements.
- The customer uses the batteries beyond the scenarios specified in this manual, including but not limited to, connecting extra loads.
- Batteries are not maintained in compliance with the requirements specified in the system manual.
- The product is damaged due to the customer's continued use of batteries beyond the warranty period.
- The product is damaged due to the use of defective or deformed batteries.
- Use the batteries provided by SUNGROW together with other batteries, including but not limited to batteries of other brands or batteries of different rated capacities.
- Product damage or property loss are caused due to storing or installing batteries together with flammable/explosive materials.

System Manual 1 Safety Precautions

Personal safety accidents and property loss are caused by battery-related operations
performed by non-qualified personnel, or by personnel not wearing qualified protective
equipment during operations.

 Batteries are damaged due to improper behaviors, such as eating, drinking, and smoking near the battery.

## 1.4 Hoisting and Transportation

#### **M** WARNING

When walking on the top of the equipment, be sure to follow the standard procedure for working at heights.

## 1.5 Installation and Wiring

#### **⚠** WARNING

In the whole process of mechanical installation, the relevant standards and requirements of the project location must be strictly observed.

#### **M** WARNING

Only equipment designated by SUNGROW can be used. Failure to use equipment designated by SUNGROW may cause damage to the protection function and injury to personnel.

# 1.6 Operation and Maintenance

#### **▲** DANGER

Dismantling or burning the battery may cause it to catch fire.

#### **⚠** WARNING

Personal protective equipment is required for maintenance and service of the equipment.

Maintenance personnel must wear protective equipment such goggles, helmets, insulated shoes, gloves, etc.

#### **MARNING**

There are no user-maintainable parts inside the battery unit.

Only personnel approved by SUNGROW can remove, replace and dispose of the batteries. Users are not allowed to maintain batteries without guidance.

1 Safety Precautions System Manual

#### **M** WARNING

To avoid electric shock, do not perform any other maintenance operations beyond those described in this manual.

If necessary, contact Sungrow Customer Service for maintenance.

#### **M** WARNING

To ensure continuous fire protection, replacement of internal components should only be performed by professional personnel.

#### **MARNING**

Protective tools such as goggles are required when carrying out coolant (glycol solution) or liquid cooling pipeline maintenance.

#### NOTICE

Do not spray paint any internal or external component of the product.

Do not use cleaning agents to clean the product or expose it to harsh chemicals.

# 1.7 Product Disposal

When the equipment or its internal components reach end-of-life, do not dispose of it together with household wastes. Some components inside the equipment can be recycled, while some may pollute the environment.

Contact an authorized local facility for collection.

# 2 Product Description

#### 2.1 Product Overview

The electrical equipment, communication device, temperature control device, and fire suppression system of the ESS all adopt an integrated design. For electrical equipment, the LFP battery system is designed with a liquid cooling system, while the PCS adopts forced air cooling for heat dissipation. The battery system and the PCS are integrated into an all-inone outdoor-type cabinet. For communication devices, the LC integrates the functions of BSC, and the CMU is built into the PCS. The integrated design makes the entire system more compact in structure and easy to maintain.

With an all-in-one design, the ESS allows flexible configuration and easy installation and O&M, with only a small space required. It also supports ancillary service functions such as demand control, gaining revenue from peak-to-trough price spread, demand response, and virtual plant.




figure 2-1 Typical Application of the ESS

\*The figure is for reference only. The real product may differ.

No.	Name
Α	ESS
В	Utility grid
С	Loads

# 2.2 External Design

# 2.2.1 ESS External Design

The external design of the ESS is shown in the figure below.




figure 2-2 External Design

<sup>\*</sup>The figure is for reference only. The real product may differ.

No.	Name
Α	LED indicator
В	Air inlet
С	Emergency stop button
D	Door lock
E	Grounding point
F	Air outlet
G	Fire inlet (Optional)
Н	Fire outlet (Optional)

#### **NOTICE**

The nameplate contains critical parameter information related to the ESS and should be protected against damages during transportation, installation, maintenance, overhaul, and other operations. Do not damage or remove the nameplate!

#### **LED Indicator**

The LED indicator is located at the top of the ESS cabinet. The description of the LED indicator status is shown as follows.

table 2-1 LED Indicator Status

Indicator Status		Description
	Steady on	The system works normally (charging/discharging)
	Blink with fading effect at	
	2s intervals	The system is normal and currently
	(breathing)	not charging/discharging
*****	Steady on	There is a fault in the system (the auxiliary power supply is not disconnected)
000000	Off	The auxiliary power supply is disconnected

#### **Emergency Stop Button**

In case of an emergency, press this button, and the system will then stop running immediately.

#### **A** DANGER

After the emergency stop button is pressed, the system will shut down and the DC contactor will open. However, the internal auxiliary power supply and the PCB board will still carry voltage. Do not touch them!

#### 2.2.2 Mechanical Parameters

#### **Overall Dimensions**

The dimensions of the ESS are shown in the figure below.




figure 2-4 Dimensions of ESS with Its Door Fully Opened

\*The figure is for reference only and the real product may differ.

# 2.2.3 Ventilation Design

The ESS has an air inlet at its front and an air outlet at its rear, as shown in the figure below.




figure 2-5 Air Inlet and Outlet

\*The figure is for reference only and the real product may differ.

# 2.3 Internal Design

# 2.3.1 Internal Components

The major electrical equipment inside the ESS cabinet are shown in the figure below.




figure 2-6 Internal Structure of ESS Cabinet

No.	Name
Α	Fire suppression system (FSS)
В	Switch gear (S/G)
С	Aerosol
D	Battery RACK (compartment)
Е	Dehumidifier(Optional)

No.	Name
F	PCS (SC110CX)
G	Liquid cooling system (LCS)
Н	Local controller (LC300)
I	Energy Management System (EMS300CP)(Optional)
J	Battery Power Supply Panel (BSP)

<sup>\*</sup>The figure is for reference only and the real product may differ.

# 2.3.2 PCS (SC110CX)

### **PCS External Design**

The external design of the SC110CX Power Conversion System (PCS) is shown in the figure below.




figure 2-7 PCS External Design

\*The figure shown here is for reference only. The real product may differ.

No.	Name	Description
1	Locating pin	Used to restrict the free movement of the PCS.
2	Vent valve	Resistant to dust and water; air permeable.
3	Guide rail	Used for the transport, installation, and removal of the
	Guide fail	device.
4	DC wiring area	-

No.	Name	Description	
5	AC wiring area	-	
6	LED indicator	Indicates the current operating status.	
7	Communication	Communication wiring area.	
	ports	Communication wining area.	
0	*Additional ground-	Terminal used for additional protective grounding, as	
8	ing terminal	specified in EN 50178.	
0	Air inlet cover	Fans are installed at the back of the cover plate, used	
9	Air iniet cover	for forced cooling.	
10	DC quitab	Used to disconnect the equipment from the battery	
10	DC switch	safely.	

# **⚠** WARNING

\* During product use, avoid DC positive/negative-to-ground short circuits and short circuits between positive and negative. Otherwise, it may lead to serious damages to the PCS.

In case a short circuit fault has occurred, the whole PCS should be replaced.

#### **LED Indicator Panel**

The LED indicator panel serves as an interface for human-machine interaction and is used to indicate the current operating status of the PCS.

table 2-2 LED Indicator Status


Indica- tor	Status	Description		
	Steady on	The device is running.		
	Blink fast	The device has connected to bluetooth and da-		
	(Interval: 0.2s)	ta communication is in process.		
		There is no fault in the device.		
Blue	Blink slow with fading effect	The device has been powered an and is in the		
2.40	(Interval: 2s)	The device has been powered on and is in the emergency stop, standby, or startup state.		
		emergency stop, standby, or startup state.		

Indica- tor	Status	Description
	Steady on	A fault has occurred (the device cannot connect to the grid).
Red	Blink	The device has connected to bluetooth and data communication is in process.  There is a fault in the device.
Off	Off	The AC and DC sides are both disconnected from power.

# 2.3.3 Battery Power Supply Panel (BSP)

### **External Design**

The external design of the BSP is shown in the figure below.



\*The figure shown here is for reference only. The real product may differ.

No.	Name	Description	
1	Locating pin	Used to restrict the free movement of the power dis-	
1	Locating pin	tribution box.	
2	Air quitlet	Used to exhaust the circulating hot air from the	
2	Air outlet	power distribution box.	
3	Air inlet	Used to bring circulating cool air into the power dis-	
	All lillet	tribution box.	
4	Connection ports 4–6	Used for power supply or communication wiring of	
		the 24Vdc device inside the cabinet.	
5	Communication port	Communication wiring area.	
6	CONN1-3	Ports for FSS, LC, and EMS.	
7	AC output port	AC output wiring area.	
	Miniature circuit breaker	AC auxiliary power supply and UPS control switch.	
8	(MCB)	AC auxiliary power suppry and OF3 control switch.	
9	*AUX POWER	Used for external auxiliary power supply wiring.	
10	Additional protective	Terminal used for additional protective grounding,	
	grounding terminal	as specified by EN 50178.	
11	AC wiring area	Connected to PCS AC side.	
12	LCS POWER	Used for power supply wiring of the liquid cooling	
1Z 	LUS PUWER	unit.	
13	UPS	Uninterruptible power supply.	
44	A O MANINI OVAVITOU:	Used to disconnect the equipment from the loads	
14	AC MAIN SWITCH	safely.	

<sup>\*</sup>The system is equipped with an internal auxiliary power supply as standard.

# 2.3.4 Battery

#### **Cell and PACK**

The PACK (battery module) is mainly composed of cells connected in series. It is equipped with functions such as battery voltage and temperature sampling and balancing control. Designed with chips dedicated to battery management, it receives control commands and uploads the collected data over daisy chain communication.

table 2-3 Cell and PACK Data - CATL

Cell	Parameter	Value
	Туре	CB310
30	Dimensions (thick-	(71.7±0.8) mm * (207.2±0.8) mm *
	ness * height * width)	(173.9±0.8) mm
	Weight	(5.34±0.20) kg
	Rated capacity	280Ah
	Rated energy	896Wh

Cell	Parameter	Value
	Rated voltage	3.2V
		2.5V-3.65V (cell temperature 0°C < T
	Voltago rango	≤55°C)
	Voltage range	2.0V–3.65V (cell temperature –30°C≤
		T ≤0°C)
PACK	Parameter	Value
	Model	P573-111/P573B-111
	Dimensions (W*H*D)	
	(wiring terminals and	(868±5) mm * (247±5) mm * (1415±5)
	faucets not	mm
	considered)	
	C Rate	≤0.5C
	Cell type	Prismatic cell with aluminum shell,
0		LFP
0	Configuration (series	1P64S
	and parallel)	
	Key components	64 cells, 1 BMU, 1 fuse
	Weight	(400±12.0) kg
	IP rating	IP65

table 2-4 Cell and PACK Data - CALB

Cell	Parameter	Value
	Туре	L173F280A
250	Dimensions (thick- ness * height * width)	(71.57±0.5) mm * (207.2±0.8) mm * (174.7±0.8) mm (with terminal) (71.57±0.5) mm * (204.57±0.8) mm * (174.7±0.8) mm (without terminal)
	Weight	(5.35±0.16) kg
	Rated capacity	280Ah
	Rated energy	896Wh
	Rated voltage	3.2V
		2.5V–3.65V (cell temperature 0°C < T ≤55°C)
	Voltage range	2.0V–3.65V (cell temperature –30°C≤ T ≤0°C)
PACK	Parameter	Value

Cell	Parameter	Value
	Model	P573AL-181/P573BL-181
	Dimensions (W*H*D) (wiring terminals and faucets not considered)	(868±5) mm * (247±5) mm * (1415±5) mm
	C Rate	≤0.5C
	Cell type	Prismatic cell with aluminum shell,
	Configuration (series and parallel)	1P64S
	Key components	64 cells, 1 BMU, 1 fuse
	Weight	(400±12.0) kg
	IP rating	IP65

### **RACK**

RACK is mainly composed of several PACKs and fuse.

RACK data is shown in the table below.

table 2-5 RACK Data - CATL


RACK Model	DC output voltage	Rated	Rated	Short-cir-
RACK Wodel	range	power	voltage	cuit current
R0229BL-ACAA	691.2-934.4V	114.7 kW	819.2V	≤20kA
R0458BL-ACCA	691.2-934.4V	114.7 kW	819.2V	≤20kA

table 2-6 RACK Data - CALB

DAOK Madal	DC output voltage	Rated	Rated	Short-cir-
RACK Model	range	power	voltage	cuit current
R0229BL-AHAA	691.2~934.4 V	114.7 kW	819.2V	≤20kA
R0458BL-AHCA	691.2~934.4 V	114.7 kW	819.2V	≤20kA

#### **RACK Structure**

table 2-7 RACK Structure



Note: RACK x-x indicates an 1P64S PACK (battery module). PCS stands for power conversion system, S/G stands for switch gear, LCS for liquid cooling unit, and BSP for battery power supply panel.

#### 2.3.5 EMS Controller (Optional)

The EMS300CP energy management system controller can collect the operation data of the ESS and upload it to the iSolarCloud so that users can monitor and control the system operation remotely.

The EMS300CP controller is optional. It is built into the ESS power distribution box. Users can read the label on the power distribution box to understand whether the product has an EMS300CP controller or not.

#### **Auxiliary Meter**

In addition to the ESS operation data, the EMS300CP also needs to collect the meter data, as required by some particular functions. Therefore, please install the following two meters first before installing the ESS.

- · Gateway meter: Zero export, demand control.
- · Electricity meter: Overload protection.

#### **Local Monitoring on Web**

The internal communication wiring between the EMS300CP and the ESS has been completed in the factory. Connect the PC to the communication port on the ESS at the site. Then, you can access the EMS300CP Web system on the PC.

The homepage of the EMS300CP Web system is shown below:




figure 2-9 EMS300CP Web Homepage

You can scan the QR code on the nameplate at the rear of the ESS cabinet to get the



EMS300CP user manual, or scan this QR code directly:

#### Remote Monitoring on iSolarCloud

You can also monitor the ESS remotely via iSolarCloud. You can log in to the iSolarCloud Web system on the PC, or download the iSolarCloud App from an application store on your





figure 2-10 EMS300CP iSolarCloud Homepage

# 2.4 Transformer Cabinet



Transformer cabinet is optional.

# 2.4.1 Cabinet Appearance

The appearance of LVS250UD is shown in the following figure.




figure 2-11 Appearance of LVS250UD

No.	Name
Α	Door lock
В	Grounding point
С	Air inlet
D	Air outlet

<sup>\*</sup> The figure is for reference only. The product received may differ.

### 2.4.2 Mechanical Parameters

The external dimensions of LVS250UD are shown in the figure.




figure 2-12 Dimensions of LVS250UD




figure 2-13 LVS250UD dimensions diagram (door open)

\*The figure is for reference only and the actual product shall prevail!

# 2.4.3 Internal Equipment

The main electrical equipment in the LVS250UD is shown in the figure below.




figure 2-14 Internal layout of the LVS250UD

<sup>\*</sup> The figure is for reference only. The product received may differ.

No.	Name
Α	Moulded case circuit breakers
В	Wiring copper bars
С	Transformer
D	Surge protection device (SPD)
E	Wiring terminals
F	AC load switch

# 3 Transport and Storage

#### 3.1 Precautions

#### **A** CAUTION

Failure to transport and store the product in accordance with the requirements in this manual may invalidate the warranty.

## 3.2 Transport Methods

The ESS can be transported by land and sea. It adopts an integrated and easy-to-lift design that facilitates transport. Currently, permission has not been granted to transport the ESS by air, and no relevant guide for rail transport is available.

The ESS can be transported by truck within the country.

#### NOTICE

In most cases, the total weight of the truck that carries the ESS will exceed the general weight limit on the road. Therefore, you may need to acquire an overweight permit from the relevant local agency in that area.

# 3.3 Transport Requirements

The ESS leaves the factory with most of its internal components fixed inside its body. You may lift or move the ESS as a whole directly during transport.

#### **M** WARNING

In the whole process of loading, unloading, and transport, follow strictly the applicable safe operation procedure for outdoor-type cabinets in the country/region where the project is located.

- All the tools used on the ESS, or during operation, must have undergone proper maintenance.
- All personnel engaged in loading, unloading, and anchoring operations should have received relevant training, especially in safety.



During the whole process of loading, unloading, and transport, always keep in mind the mechanical parameters (overall dimensions and weight) of the ESS.

System Manual 3 Transport and Storage

To transport and move the ESS, make sure the below requirements are met:

- All the doors of the ESS are locked.
- Select an appropriate crane or lifting tool according to the on-site conditions. The tool used must have a sufficient load capacity, boom length, and swing radius.
- It is recommended to use one crane to lift the ESS.
- Extra traction may be required to move the ESS along a slope.
- Remove all obstacles that exist or may exist along the route, such as tree branches and cables.
- Transport or move the ESS in good weather, whenever possible.
- Be sure to set up warning signages or fence off warning zones to prevent irrelevant personnel from entering the operating area, thus avoiding accidents.
- Do not put the ESS upside down, nor stack them up, during transport.
- If the ESS is transported by land, be sure to secure the lifting rings at the top of the ESS
  to the transport vehicle using ropes, to prevent it from getting overly tilted during
  transport.



After the ESS arrives at the project site, remove the diagonal fixing pieces at the top four corners of the equipment, and keep them properly.

# 3.4 Storage Requirements

- The ESS base must be elevated off the ground to a certain height, to avoid condensation inside the ESS and prevent the ESS bottom from getting soaked by rain water in rainy seasons. The height should be decided according to the on-site geological and meteorological conditions, etc.
- Keep the ESS on a dry, flat, and solid platform that has a sufficient load capacity and is
  not covered by any vegetation. The surface where the ESS is stored must be flat, without
  bumps or rolls-and-swells. It should have an unevenness of ≤ 5mm and be free of water
  accumulation.
- During storage, ensure that the doors of the ESS and all its internal components are locked.
- During storage, maintain a space of 200 cm at the front of the cabinet and a space of 60 cm at the back.
- Storage ambient temperature: -30°C to +50°C; recommended storage temperature: -30°C to 25°C.

Make proper adjustments according to the coefficients listed below if the equipment is stored at other temperatures.

3 Transport and Storage System Manual

Temperature range	Attenuation Adjustment Coefficient
26°C to 40°C	0.1%/month
41°C to 50°C	0.3%/month
51°C to 60°C	0.6%/month

- Long-term storage of the battery is not recommended as it may lead to battery capacity
  attenuation. Even if the battery is stored at the most recommended storage temperature,
  irreversible capacity attenuation will still happen during the period of rest, and such attenuation will become severer as the storage time lengthens. Please refer to the technical agreement for the specific amount of attenuation.
- The UPS that is not put into operation needs to be charged once every six months.
- The relative humidity of the storage environment should be between 0% and 95%, non-condensing.
- Take effective measures to protect the air inlet and outlet of the ESS and prevent the ingress of rainwater, sand, and dust into the equipment.
- Carry out routine inspections. Perform routine inspections at least every half a month. Inspect the packaging for intactness and signs of damage caused by pests or animals. Repackage the equipment immediately if the packaging gets damaged. Inspect the ESS cabinet and its internal components for damages.
- Before installing an ESS that has been stored for more than six months, open the door
  and conduct a visual inspection first. Make sure the ESS and its internal components are
  all intact without any damage. Meanwhile, perform inspections after powering on and
  starting up. If necessary, ask qualified personnel to test the equipment before installation.
- PACKs should be stored in a clean and dry place and must not be left out in the heat of the sun or rain. The place must be free of hazardous gas, flammables, explosives, or corrosive chemicals. Besides, avoid mechanical shock, great pressure, strong magnetic field, or direct sunlight.
- Avoid damages to the PACK caused by severe environmental conditions such as sudden temperature changes or collisions.
- The packing crate cannot be tilted or turned upside down.

If the ESS has been stored for over 6 months (from the date it is delivered from SUNGROW) under the required conditions mentioned above, perform charging/discharging once until the system SOC reaches 30%–40%. Make sure the SOC value is consistent after re-charging.

# 4 Mechanical Installation

#### **M** WARNING

During the whole process of mechanical installation, the relevant standards and requirements of the project site must be strictly observed.

# 4.1 Inspection Before Installation

### 4.1.1 Deliverables Inspection

Check whether deliverables are complete against the attached packing list.

## 4.1.2 Equipment Inspection

- Check whether the product you have received matches the order you have placed.
- Inspect the product and its internal components, and make sure there is no damage.
- If the product is equipped with an EMS300CP controller, ensure the gateway meter and electricity meter used with the EMS300CP have been installed before commissioning.

In case of any problem or doubt, contact your transport service provider or SUNGROW in time.

#### **M** WARNING

 Proceed with installation only if the equipment is intact without any signs of damage!

Before installation, ensure that:

- · The product is in good condition, without any damage.
- · All the components inside the product are intact without any signs of damage.

# 4.2 Installation Environment Requirements

# 4.2.1 Installation Site Requirement

- The climate environment and geological conditions, such as stress wave emission and underground water level, should be fully considered when selecting the installation site.
- The environment around the installation site should be dry and well ventilated.
- There should be no trees around the installation site to prevent branches or leaves blown off by heavy winds from blocking the door or air inlet of the energy storage system.
- The installation site should be away from areas where toxic and harmful gases are concentrated, and free from inflammable, explosive and corrosive materials.

It is suggested the product be installed in a place away from the residential area. Ensure
the distance and noise requirements specified by the local laws and regulations are met.
If the requirements cannot be met due to geographical restrictions, use noise mitigation
measures. For detailed solutions, consult with the designer or SUNGROW.

- Avoid installing the battery container in dusty environments with a large amount of dust, smoke, or floc. These particles may cling to the air inlets/outlets or heat sink of the battery container, thus impairing its heat dissipation performance or even getting it damaged.
- Avoid installing the battery container in places where corrosive gas or dust may be produced or accumulated, or in places within 30km (20 miles) of saline-alkaline land or pollution-generating industrial complex such as chemical plants and power plants (chemical gas class: 1C1, solid particle level: 1S2).
- Do not install the battery container in environments contaminated with halogen or sulfur pollutants.
- There are no underground facilities at the site.

#### NOTICE

Do not install the device in an environment with vibration and strong electromagnetic field. Strong-magnetic-field environments refer to places where magnetic field strength measures over 30 A/m.

## 4.2.2 Foundation Requirements

#### **M** WARNING

Considering the equipment's heavy weight, before foundation building, perform a thorough inspection on the installation site first (from the aspects of geology, environment, and climate, etc.). Foundation design and construction can be carried out only after confirming that the installation site meets all relevant requirements.

An improperly built foundation may lead to difficulties or troubles in equipment mounting, opening and closing of cabinet doors, and future operation of the equipment. Therefore, the foundation must be designed and constructed in compliance with certain standards, to meet the requirements of mechanical support, cable laying, and future maintenance.

Make sure at least the below requirements are met during foundation building:

- The bottom of the foundation pit must be compacted, filled and made even.
- The foundation should be built in compliance with the foundation drawing provided, or approved, by SUNGROW. The tolerance for the upper surface of the foundation is ±5mm.
- The foundation should provide sufficient and effective support for the equipment.
- The equipment should be positioned in a higher place, to protect its base and interior from rain erosion. It is recommended to build a foundation about 300mm higher than the horizontal ground on site.

System Manual 4 Mechanical Installation

Set up a proper drainage system based on the local geological conditions.

 Build a cement foundation with sufficient cross-sectional area and height. The foundation height should be determined by the constructor based on the on-site geological conditions.

Take cable laying into consideration when building the foundation.



In the process of foundation building, remove the muck immediately after excavation, to avoid affecting the hoist and transport of the equipment.

- Build a platform around the foundation to facilitate future maintenance.
- During the foundation building, reserve sufficient space for the AC side cable trench according to the position and size of the cable inlet and outlet on the equipment, and embed the cable conduit in advance.
- Determine the specifications and quantity of the perforating gun according to the model and quantity of cables used.
- Both ends of each embedded conduit should be temporarily sealed off to prevent the ingress of foreign objects. Otherwise, it may lead to difficulties in wiring.
- After all the cables are connected, seal off the cable inlet and outlet and the connectors
  with fireproof mud or other suitable materials, to prevent rodents from entering the
  equipment.



Pre-bury the grounding unit according to the applicable standards of the country/region where the project is located.

# 4.2.3 Installation Space Requirements

For better heat dissipation and ease of maintenance, it is recommended to reserve sufficient space around the ESS during installation.

#### NOTICE

The distance here refers to the distance from the wall or other equipment to the ESS cabinet, not to the ESS foundation.

# Installation of One ESS




figure 4-1 Space Required for One ESS

Maintenance Item	Space Requirements
Maintenance tool- ing for non-PACK	L1≥300mm, L2≥430mm, L3≥2500mm, L4=0
components PACK mainte-	
nance tooling	L1≥300mm, L2≥630mm, L3≥2000mm, L4≥400mm



When the system is configured with inlet/exhaust fans, the distance of L1 must be increased to 600mm.

System Manual 4 Mechanical Installation

# Installation of Multiple ESSs




figure 4-2 Space Required for ESSs in One Row

Maintenance Item	Space Requirements		
Maintenance tool-			
ing for non-PACK	L1≥300mm, L2≥430mm, L3≥2500mm, L4=0		
components			
PACK mainte-	14>200mm 12>620mm 12>2000mm 14>400mm		
nance tooling	L1≥300mm, L2≥630mm, L3≥2000mm, L4≥400mm		



When the system is configured with inlet/exhaust fans, the distance of L1 must be increased to 600mm.




figure 4-3 Space Required for ESSs in Two Rows

Maintenance Item	Space Requirements
Maintenance tool-	
ing for non-PACK	L1≥600mm, L2≥430mm, L3≥2500mm
components	
PACK mainte-	L1≥600mm, L2≥630mm, L3≥2000mm
nance tooling	L1200011111, L22030111111, L322000111111

<sup>\*</sup> The figure is for reference only. The product received may differ.



When arranging the ESS cabinets in two rows, ensure that the two rows are aligned on both sides. Avoid misaligned arrangements to minimize the risk of hindered heat dissipation.

# Space Required for ESS\*2 + LVS\*1 (Non-open Foundation)

When the energy storage system is applied in off-grid scenarios, the ESS cabinet needs to be equipped with the transformer cabinet. A transformer cabinet can be matched with one ESS cabinet or two ESS cabinets. For specific spacing requirements, the scenario of one transformer cabinet with two outdoor cabinets is taken as an example.

System Manual 4 Mechanical Installation

When a transformer cabinet is matched with two outdoor cabinets, the required spacings between outdoor cabinets and transformer cabinets are shown in the following figure.




figure 4-4 Cabinets Installed on Non-open Foundation

Maintenance Item	Space Requirements		
Maintenance tool-	L1≥300mm, L2≥400mm, L3≥2500mm, L4=0		
components	L1230011111, L22400111111, L322300111111, L4-0		
PACK mainte-	L1≥300mm, L2≥400mm, L3≥2000mm, L4≥400mm		
nance tooling	E1=000111111, E2=400111111, E0=2000111111, E4=400111111		

# Space Required for ESS\*2 + LVS\*1 (Open Foundation)

For installations on open foundations (such as a pile foundation) where there are no obstructions to the bottom air inlet of the transformer cabinet, the transformer cabinet can be positioned closely against the ESS base with no gap in between. The required distances between the cabinet and the walls or other equipment are illustrated in the figure below.




figure 4-5 Cabinets Installed on Open Foundation

Maintenance Item	Space Requirements	
Maintenance tool-		
ing for non-PACK	L1≥300mm, L2≥400mm, L3≥2500mm, L4=0	
components		
PACK mainte-	14>200mm 12>400mm 12>2000mm 14>400mm	
nance tooling	L1≥300mm, L2≥400mm, L3≥2000mm, L4≥400mm	

<sup>\*</sup> The figure is for reference only. The product received may differ.



Please decide whether to equip the LVS250UD cabinet based on the project's specific requirements.

#### With Obstructions in Heat Dissipation Path

If the ESS is installed indoors or if there are significant obstructions in the air outlet pathway, add ventilation equipment to enhance heat dissipation. The temperature at the air inlet must not exceed 45°C to ensure long-term stable operation of the system.

For indoor installation, ensure that the distance from the top and two sides of the ESS to any obstructions that could hinder heat dissipation, such as walls, meets the following requirements:

• For an ESS with one side against an obstruction, maintain a space of ≥800mm above the cabinet for effective ventilation.

System Manual 4 Mechanical Installation

#### **NOTICE**

Ensure a ventilation rate of 2500m<sup>3</sup>/h and a cooling capacity of 7kW at the air outlet on the rear of each ESS cabinet.

#### NOTICE

Outdoor installations where heat dissipation is significantly compromised by large obstructions above or beside the cabinet should be treated as indoor installations. In such cases, the distance from the cabinet to the obstruction must comply with the same requirements specified for indoor installations.

 Installing the ESS outdoors is recommended, as per the general plant design standards.



 For cabinets installed indoors due to layout constraints, SUNGROW specifies indoor arrangement requirements from the perspective of product design and maintenance only. The owner/EPC shall consider plant-level requirements in these cases

#### 4.3 Handle with Forklift

The ESS can be moved using a forklift if the ground on the installation site is flat. Forklift pockets are provided at the bottom of the ESS for the insertion of forklift forks.

To move the ESS using a forklift, make sure the below requirements are met:

- · The forklift has sufficient load capacity.
- The forks are long enough for moving the equipment.

The forks should be inserted into the forklift pockets at the bottom of the equipment (see the figure below for the positions of the pockets). The depth of the forks inserted into the pockets should be the depth of the pockets.

- Handle, move, and place the ESS slowly and steadily. It is suggested to try a little first before handling, to make sure all requirements are met.
- Position the ESS on a stable surface only, and this place should be free of obstacles or protrusions, with good drainage.




figure 4-6 Handle with Forklift

#### **M** WARNING

- Move the ESS using a forklift by the bottom forklift pockets.
- Never insert the forklift forks into any position on the equipment else than the bottom pockets.



The ESS will be delivered with forklift pockets exposed to air. It is suggested to cover the pockets with sealing plates after the installation is completed. The sealing plates are included in the accessories.

System Manual 4 Mechanical Installation

# 4.4 Hoisting

#### 4.4.1 Precautions

Strictly adhere to safe operating procedures throughout the hoisting process to ensure the safety of operators, equipment, and the surrounding environment.

#### Requirements for Hoisting

- Qualifications:
  - Engage a qualified specialized hoisting service provider to perform the hoisting.

#### Foundation:

- Ensure sufficient space is reserved in the cable trench, and the cable conduit is embedded in advance.
- Clearly mark the designated area for the equipment on the foundation with lines.
- Prior to hoisting, recheck the flatness of the foundation. The flatness deviation must not exceed 10 mm, and the slope must not exceed 5°.
- Correct any excessive deviations in flatness or slope, or prepare in advance an adequate number of metal washers that match the sizes of the load-bearing points.
- If the system includes a SUNGROW battery cabinet and a firewall is present on site, ensure that the designated area for the battery cabinet is ≥ 150 mm away from the firewall.
- · Familiarity with Equipment Arrangement
  - Properly determine the order of trailer arrivals at the site based on the project's equipment layout. Vehicles carrying lifting devices have priority for entry.
  - Determine the positions and orientations of all equipment.
  - If the system includes SUNGROW battery cabinets, ensure that all battery cabinets within the same block are of the same grade.
- Equipment Status:
  - Verify that all equipment and lifting devices have undergone inspections, and that cabinet doors are securely closed and locked.

#### Selection of Cranes

The load capacity of the crane should be determined based on the weight of the load to be lifted, the crane's operating zone (operating radius and range of motion) and design parameters, the foundation conditions, and the specific hoisting requirements.

#### **MARNING**

Before hoisting, select an appropriate crane with sufficient load capacity based on an evaluation by a qualified hoisting service provider to ensure operation safety. SUNGROW shall not be held liable for any damages resulting from the use of inappropriate cranes.

#### **Lifting Device Requirements**

 Please use the lifting devices provided by SUNGROW (slings, shackles, and lifting beams).

 If it is necessary to use slings and shackles that are not provided by SUNGROW due to special circumstances, ensure that the selected lifting devices meet the requirements specified in "4.4.2 Hoisting System".

# **Safety Instructions**

#### **MARNING**

Perform operations in strict accordance with the local safe operating procedures relevant to the country or region, including but not limited to:

- Stop hoisting immediately in severe weather conditions, such as heavy rain, fog, or strong winds.
- Set up warning signages or fence off a warning zone to prevent irrelevant personnel from entering the operating area, thus avoiding personal injury or death.
- Ensure that all personnel engaged in hoisting, loading, unloading, and anchoring operations have received relevant training, especially in safety.
- Do not stand directly beneath or within 10 meters of any moving equipment to avoid personal injuries or fatalities.
- · Conduct all work under the guidance of qualified technical personnel on site.
- Ensure that all tools and equipment used during the operation have undergone proper maintenance.
- · Lift and lower the equipment gently, avoiding any dragging or collisions.
- · Do not proceed with hoisting in low light conditions or when vision is not clear.
- Do not proceed with hoisting if there is any person or moving or movable objects on top of the equipment.

System Manual 4 Mechanical Installation

# 4.4.2 Hoisting System




figure 4-7 Hoisting System of ESS

\*The figure shown here is for reference only. The real product may differ.




figure 4-8 Hoisting System of LVS250UD

<sup>\*</sup>The figure shown here is for reference only. The real product may differ.

 If using slings or shackles not provided by SUNGROW, ensure that their specifications meet the requirements listed above. Request the hoisting service provider to conduct a thorough evaluation before proceeding with the hoisting.



- The short slings above the lifting beam each have a length of 4 m and are folded for use. If using the slings unfolded, ensure that each sling has a rated load capacity of 30 t.
- · After hoisting, store the lifting devices properly for future use.

### 4.4.3 Hoisting Procedure

Step 1 Secure the lifting devices.

- 1 Attach four shackles to the four loops at both ends of the two slings.
- 2 Connect the four shackles on the two slings to the top lifting rings of the equipment.
- 3 Hang the two slings directly onto the lifting hook. Ensure the hook is positioned in the middle of the sling.

Step 2 Lift the equipment smoothly and stably.

- 1 Suspend lifting when the equipment is lifted 300 mm off the supporting surface. Then, check the connections between the slings and the equipment.
- 2 Ensure that the connections between the slings and the equipment are all secure and that the angle of the equipment relative to the horizontal plane is less than 5° after it settles naturally. Once confirmed, continue with the lifting.

Step 3 Lay the equipment down steadily in the designated area marked by lines on the foundation.

**Step 4** Check and adjust the load-bearing points.

- 1 Verify that the equipment doors open and close normally, that the equipment frame shows no signs of deformation, and that the equipment rests securely and evenly on the supporting surface.
- 2 If any deformation is detected, lift the equipment slowly and add washers at the loadbearing points. Then, lower the equipment again gradually, until it is fully seated with each load-bearing point completely bearing the weight.

Step 5 Remove the lifting devices.

#### - - End

Ensure the equipment is securely and fully seated on the foundation within the designated area and neatly positioned. Verify that the equipment is free from deformation and that its doors open and close smoothly.

#### NOTICE

After hoisting, properly store the lifting devices provided by SUNGROW for future use.

System Manual 4 Mechanical Installation

# 4.5 Cabinets Fixing

After moving the cabinets to the target position, fix it in place. You can fix the equipment by welding or using L-shaped angle steels.

# Fixed by welding

Fix the cabinets bottom to the foundation by welding. Apply anti-corrosion treatment to the welding points after welding is completed.

# Fixed with L-shaped angle steels

As shown in the figure below, mounting holes for L-shaped angle steels are provided at the bottom of the cabinets .





figure 4-9 L-shaped Angle Steels

## **Installation Tools**


Tools that may be used when installing the L-shaped angle steels are as follows:

No.	Name	Source	
1	Marker	Not included in the scope of supply	
2	Hammer drill	Not included in the scope of supply	
3	Angle steel	Included in the scope of delivery	
4	M16 expansion bolt	Not included in the scope of supply	
5	M16 screw	Included in the scope of delivery	

#### **Installation Method 1**



**Installation Method 2** 





Please choose the installation method according to the actual situation.

# 5 Electrical Connection

### 5.1 Precautions

#### **▲** DANGER

High voltage! Electric shock!

- It is strictly forbidden to directly touch the live parts in the unprotected state!
- Before installation, ensure that the all switches are off.

# **M** WARNING

Sand and moisture penetration may damage the electrical equipment in the system, or affect their operating performance!

- Avoid electrical connections during sandstorms or when the relative humidity in the surrounding environment is greater than 95%.
- Perform electrical connection when there is no sandstorm and the weather is fair and dry.

#### **M** WARNING

- Before wiring, check and ensure that the polarity of all input cables is correct.
- During electrical installation, do not forcibly pull any wires or cables, as this may compromise the insulation performance.
- Ensure that all cables and wires have sufficient space for any bends.
- Adopt the necessary auxiliary measures to reduce the stress applied to cables and wires.
- After completing each connection, carefully check and ensure that the connection is correct and secure.

#### **MARNING**

When an external short circuit occurs in the RACK circuit and the switch box fuse produces a protective action, the fuse and the two DC contactors must be replaced at the same time.

#### 5.2 Electrical Connection Overview

The wiring diagram of the ESS is shown below:






figure 5-1 ESS Wiring Diagram (On-grid)




figure 5-2 ESS-LVS Wiring Diagram (Off-grid)

table 5-1 Interface Description

No.	Name	*Recommended cable specifications	
^	AC output port	3×95mm <sup>2</sup> /copper wire	
Α	Ac output port	3×150mm²/aluminum wire	
В	LC communication port (con-	2×1.5mm² shielded twisted-pair cable	
ь	nection port 1)		
С	Ethernet communication port	CAT6A S/FTP network cable	
D	External power supply	3×4mm²/copper wire	
F	Crounding point	70mm <sup>2</sup> –95mm <sup>2</sup> yellow-green cable or	
	Grounding point	grounding flat steel	
F	LVS250UD AC side to load	240 mm <sup>2</sup> /copper wire	

<sup>\*</sup>The above cables are not included in the scope of delivery and should be prepared separately.

#### **MARNING**

- Electrical connections must all be performed in strict accordance with the wiring diagram.
- Electrical connections must all be performed when the equipment is completely voltage-free.

#### **M** WARNING

Operations related to the electrical connection must only be performed by qualified electrical engineers, all in compliance with the "Safety Precautions" specified in this manual. SUNGROW shall not be held liable for any personal injury or property damage arising from failure to follow the safety instructions.

# **NOTICE**

- Installation and wiring of the ESS must conform to the applicable standards or regulations in the country/region where the project is located.
- Wiring or installation not in accordance with the relevant instructions provided in this manual may result in equipment or system failure, which will not be covered by the warranty.


The EMS is optional.



- The dehumidifier is optional. The CONN3 interface reserveds for dehumidifier power supply input.
- The system is equipped with an internal auxiliary power supply as standard.
- Each transformer cabinet can be adapted to one or two ESS cabinets.

# 5.3 Preparation Before Wiring

# 5.3.1 Prepare Installation Tools



# 5.3.2 Open Cabinet Door

Open the cabinet door before wiring.




figure 5-3 Open the Front Door

Step	Description
1	Door locked
2	Move the cover above the lock hole
3	Insert the door key and turn it clockwise
	Rotate the handle counterclockwise to the position shown in the figure to open
4	the front door

# 5.3.3 Prepare Cables

#### **A** DANGER

Before electrical connection, check and ensure that the cables are all intact and well-insulated. Poor insulation or cable damage may result in safety hazards. If necessary, replace the cable immediately.

The cables must meet the following requirements:

- The current carrying capacity of the cable meets requirements. Factors affecting the current carrying capacity of a conductor include but are not limited to:
  - Environmental conditions;
  - Type of the insulation material of the conductor;
  - Cabling method;
  - Material and cross-sectional area of the cable.
- Select cables with a proper diameter according to the maximum load, and the cables should be long enough.
- Ensure that all cables and wires have sufficient space for any bends.
- During electrical connection, do not forcibly pull any wires or cables, as this may diminish their insulation performance.
- All DC input cables must be of the same specifications and materials.
- AC output cables of three phases must be of the same specifications and materials.
- · Only flame retardant cables can be used.

 Keep a sufficient distance between the cables and the heat-generating components, to prevent the cable insulation layer from aging or getting damaged due to high temperature.

- After completing each connection, carefully check that the connection is correct and secure.
- Adopt necessary auxiliary measures to reduce the stress applied to cables and wires.
- Select cables with appropriate cross-sectional areas, according to the actual environmental conditions for heat dissipation of the cables laid on-site.
- Select communication cables equipped with corresponding shielding protection features according to the requirements of SUNGROW.
- Secure the power cables and the communication cables separately. Ensure a minimum space of 10cm between the lines of strong and weak electricity to avoid electromagnetic interference.
- Inspect the connection between the wiring terminal and the copper bar. If any part of the heat-shirk tubing is caught between them, remove it immediately. Otherwise, it may lead to poor contact or even damage due to heat.


#### NOTICE

- The cables used should comply with requirements of local laws and regulations.
- The cable color in figures in this manual is for reference only. Please select cables according to local standards.

#### Crimp terminal

Crimp OT/DT terminals

Follow the steps shown below to crimp terminal.



No.	Description	No.	Description
1	Heat shrink tubing	2	OT/DT terminal
3	Hydraulic pliers	4	Heat gun

# 5.3.4 Copper Wire Connection

When copper cables are selected, the connection sequence of wiring parts is shown in the following figure.




figure 5-4 Copper cable terminal connection sequence

No.	Name	No.	Name
A	Copper bus bar	D	Spring washer
	Copper connection		Flat washer
В	terminal	E	riai wasilei
С	Bolt	F	Nut

# NOTICE

Bolt fastening should be firm and reliable, and the exposed wire buckle should not be less than 2 buckles.

### 5.3.5 Aluminum Wire Connection

When the aluminum wires are selected, a copper-to-aluminum adapter terminal is needed as shown below:




figure 5-5 Copper-to-aluminum adapter terminal connection

No.	Name	No.	Name
A	Copper bus	D	Spring washer
	copper-toaluminum	_	Fl-4
В	adapter terminal	E	Flat washer
С	Bolt	F	Nut

# **NOTICE**

Bolt fastening should be firm and reliable, and the exposed wire buckle should not be less than 2 buckles.

# 5.3.6 Cable Inlet Design

Cables connecting the external devices to the ESS can be led through the cable inlet at the bottom of the ESS.




figure 5-6 Schematic diagram of BESS inlet and outlet




figure 5-7 Schematic diagram of LVS250UD inlet and outlet

# 5.4 Ground Connection

# **NOTICE**

Grounding must be completed by strictly following the applicable local standards and regulations.

#### **NOTICE**

• Before grounding, clean the periphery of the threaded port of the grounding point and the surface of the grounding point, to ensure reliable grounding.

After grounding, apply anti-corrosion treatment for the entire grounding area.

#### Overview

Grounding can be made in the following two ways: welding a grounding flat steel, or connecting a grounding cable. For the location of the grounding point, see "ESS External Design".



Devices installed on-site by users (such as wireless routers) should be properly grounded by connecting to a nearby grounding point.

#### **Grounding Flat Steel (Recommended)**

Remove the protective tape from the grounding point and weld the hot-dip galvanized flat steel to the grounding point (the area where the flat steel and the ESS are joined together should be 40mm x 70mm). Spray paint the whole fixing area after completing welding.




figure 5-8 BESS grounding diagram

<sup>\*</sup>The figure is for reference only and the actual product shall prevail.




figure 5-9 LVS250UD grounding diagram

\*The figure is for reference only and the actual product shall prevail.




Transformer cabinet is optional.

#### **Grounding Cable**

Use a 70 mm<sup>2</sup>–95 mm<sup>2</sup> copper grounding cable to connect the target grounding point to the grounding point on the ESS properly and reliably (the grounding point is covered with protective tape upon delivery, which should be removed before wiring).

Crimp the DT terminal. For details, see "5.3.3 Prepare Cables". Secure the DT terminal to the wiring hole with an M10 bolt at a tightening torque of 34–40N.m.



\*The figure is for reference only and the actual product shall prevail.

Carry out external ground connection in compliance with the actual on-site conditions and the instructions by the plant staff.

Measure the ground resistance after completing the grounding. Make sure the resistance does not exceed  $4\Omega$ .



The specific ground resistance should comply with the applicable national/local standards and regulations.

# 5.5 AC Connection

## 5.5.1 Safety Precautions

#### **MARNING**


Accidental touching of live terminals can cause fatal electric shock!

- Ensure that the AC/DC switches of the DC/AC power converter unit are open, and that the wiring terminals are dead.
- Connecting to the power grid must be approved by the relevant department and comply with all power-related safety instructions and specifications.

# **MARNING**

- When connecting to the AC grid, disconnect the upstream AC side circuit breaker to ensure that there is no voltage at the contact terminals.
- Connect to the grid only if approved by the utility grid and all relevant safety instructions are followed.
- The AC output is not grounded inside the device.
- The DC and AC circuits are isolated from the enclosure. If required by the relevant national electrical codes, the installer is required to connect the system.

# 5.5.2 Overview of the Wiring Area



Connected to Grid

figure 5-10 ESS Wiring Overview (On-grid)




figure 5-11 ESS+LVS Wiring Overview (Off-grid)



- Transformer cabinet is optional.
- A transformer cabinet can be matched with one ESS cabinet or two ESS cabinets.

# 5.5.3 ESS AC Output Wiring

- **Step 1** Turn off the upstream AC circuit breaker and measure with a multimeter to ensure no voltage is present at the terminals.
- **Step 2** Lead the cable to the AC wiring area inside the cabinet through the cable inlet.

**Step 3** Make sure the AC cables are connected properly in the correct positions.




figure 5-12 AC Wiring Area

**Step 4** Strip the protective layer of the cables using wire strippers to expose the copper cores.

Step 5 Crimp the OT terminals. For details, see "5.3.3 Prepare Cables".

Step 6 Secure the terminals to the wiring holes of ESS or LVS250UD with bolts.

- ESS: Secure the OT terminals to the wiring holes with M12 bolts at a tightening torque of 40 N·m (for detailed wiring instructions, please refer to "5.3.4 Copper Wire Connection" and "5.3.5 Aluminum Wire Connection".
- LVS250UD: Secure the OT terminals to the wiring holes with M10 bolts at a tightening torque of 34~40 N·m (for detailed wiring instructions, please refer to "5.3.4 Copper Wire Connection" and "5.3.5 Aluminum Wire Connection".

**Step 7** Pull gently the cables backward after wiring to ensure the cables are long enough.

**Step 8** Close the protective cover for terminals, fasten the protective buckles on both sides, and tighten the four screws.

#### **NOTICE**

- Perform wiring in strict accordance with the correct phase sequence.
- --End

# 5.5.4 LVS250UD-Load Connection Steps



Transformer cabinet is optional.

- Step 1 Make sure the upstream and downstream switches are disconnected.
- **Step 2** Pass the cables into the LVS250UD cabinets from the inlet holes.

Step 3 Make sure that the AC cable connection sequence is correct.




figure 5-13 LVS250UD-Load wiring area

\*The figure is for reference only and the actual product shall prevail.

- Step 4 Strip the protective layer of the cable to expose the copper core of the wire with strippers.
- Step 5 Crimp with OT terminal, refer to "5.3.3 Prepare Cables".
- **Step 6** Secure the OT terminal to the wiring hole by M10 bolt with a tightening torque of 34~40 N·m. Refer to the "5.3.4 Copper Wire Connection" and "5.3.5 Aluminum Wire Connection" connection sequence for installation.
- **Step 7** Pull the cable back slightly after wiring to ensure that the cable is long enough.

## NOTICE

- · Strictly follow the phase sequence to connect cables.
- --End

# 5.6 Auxiliary Power Supply Wiring

Devices of the system, such as the internal liquid cooling unit, 24Vdc device, and fans, are powered by an external or internal auxiliary power supply. Internal auxiliary power supply is used for this system by default.

#### **Power Supply Mode**

The auxiliary power supply of the system includes the internal auxiliary power supply and the external auxiliary power supply:

- If the external auxiliary power supply is adopted, use the auxiliary power supply port inside the ESS power distribution box for wiring.
- If the internal auxiliary power supply is adopted, use the internal auxiliary power supply terminal inside the BSP for wiring before delivery.

#### Steps for External Auxiliary Power Supply Wiring

**Step 1** Make sure the circuit breakers of the upstream and downstream equipment are all in the open state.

- Step 2 Pass the cable through the cable inlet/outlet into the ESS.
- **Step 3** Make sure the AC cables are connected properly in the correct positions.

table 5-2 Port Definition

Mode	Port	Description	*Recommended cable specifications
400Vac external power supply	Auxiliary power supply L1	Phase L1	- 4mm²
	Auxiliary power supply L2	Phase L2	
	Auxiliary power supply L3	Phase L3	-

<sup>\*</sup>These are recommended cable specifications. You may make adjustments based on your actual needs.

**Step 4** Complete the wiring by referring to the port marks on the cabinet and the above port definitions. After completing the wiring, secure the terminals at a tightening torque of 5 N·m.

#### - - End



This product comes with internal auxiliary power supply as standard. If an external auxiliary power supply is needed, contact SUNGROW for wiring solutions.

# 5.7 EMS/LC/FSS External Power Supply Wiring

CONN1/2/3 on the power distribution box are used for the wiring of the EMS, the LC, and the external power supply of the FSS.

The positions of CONN1, CONN2, and CONN3 are shown below.




figure 5-14 Communication Ports

CONN1-3/4 tact input (DIN10)  CONN1-5/6 Reserved for LC "transformer cabinet fault linkage control" digital output (DO1)  CONN1-7/8 Reserved for dehumidifier power supply input  CONN1-9/10 Reserved for 24Vdc power supply interface	Port	Position	Definition		
CONN1-3/4 tact input (DIN10)  CONN1-5/6 Reserved for LC "transformer cabinet fault linkage control" digital output (DO1)  CONN1-7/8 Reserved for dehumidifier power supply input  CONN1-9/10 Reserved for 24Vdc power supply interface	CONN1	CONN1-1/2	Reserved for DIN dry contact input		
CONN1-5/6  control" digital output (DO1)  CONN1-7/8  Reserved for dehumidifier power supply input  CONN1-9/10  Reserved for 24Vdc power supply interface		CONN1-3/4	Reserved for LC "transformer cabinet fault" dry contact input (DIN10)		
CONN1-9/10 Reserved for 24Vdc power supply interface		CONN1-5/6	•		
		CONN1-7/8	Reserved for dehumidifier power supply input		
2.00		CONN1-9/10	Reserved for 24Vdc power supply interface		
CONN2-1/2 CMU communication, reserved for maintenance	CONN2	CONN2-1/2	CMU communication, reserved for maintenance		
CONN2-3/4 PCS parallel communication		CONN2-3/4	PCS parallel communication		
CONN2-5/6 Reserved		CONN2-5/6	Reserved		
CONN2-7/8 FSS "heat detector triggered" dry contact output		CONN2-7/8	FSS "heat detector triggered" dry contact output		
00		CONN2-9/10	FSS "smoke detector triggered" dry contact output		
CONN2-11/12 FSS "aerosol extinguishant spraying" dry contact output		CONN2-11/12			
CONN2-13/14 Reserved		CONN2-13/14	Reserved		
CONN3-1/2 Reserved for EMS RS485 communication	CONN3	CONN3-1/2	— Reserved for FMS RS485 communication		
		CONN3-3/4	- Neserved for Eivis NS403 Communication		
CONN3-5/6 Reserved for EMS dry contact input (DI1)		CONN3-5/6	Reserved for EMS dry contact input (DI1)		

Port	Position	Definition
	CONN3-7/8	Reserved for EMS digital output (DO1)
	CONN3-9/10	"Flammable gas detecter" dry contact input
	CONN3-11/12	Reserved for 24Vdc power supply interface of ATS
	CONN3-13/14	Reserved for fire ventilation input



Transformer cabinet is optional.

• If there is no transformer cabinet, positions 3–6 of CONN1 do not need to be wired.



- If there is no EMS, positions 1–8 of CONN3 are invalid.
- If there is no ATS, positions 1–2 of CONN1 and 11–12 of CONN3 are invalid.
- If there is no fire ventilation, positions 13–14 of CONN3 are invalid.

# 5.8 Fault Dry Contact Signal Connection (Off-grid)

The cable from the transformer cabinet is connected to the ESS cabinet for the transmission of dry contact signals such as transformer cabinet fault signal and fault linkage signal between ESS cabinets. The output port is located on the XK1 terminal block of the transformer cabinet and the input port is located on the CONN1 terminal block of the ESS cabinet.

- Step 1 Confirm that the circuit breakers of the front and rear equipment are all off.
- **Step 2** Pass the cables out of the transformer cabinet and into the ESS cabinet through the inlet and outlet holes.

Step 3 Make sure that the cables are connected in the correct order.




table 5-3 Port description

Cabinet	Mark	Description	*Recommended specification
	XK1-1	Connected to	− 1.5 mm²
Transformer	AN 1-1	CONN1-3 of 1#ESS	
cabinet	XK1-12	Connected to	
		CONN1-4 of 1#ESS	
	1#ESS-	Connected to	
FCC ashinat	CONN1-5	CONN1-3 of 2#ESS	- 1.5 mm <sup>2</sup>
ESS cabinet	1#ESS-	Connected to	
	CONN1–6	CONN1-4 of 2#ESS	

<sup>\*</sup>The noted cable specifications are recommended values. It can be adjusted according to actual needs.



Transformer cabinet is optional.

**Step 4** Wiring according to the port identification and definition. Tighten with a screwdriver with a torque of 0.7±0.1 N·m.

- - End

# 5.9 Ethernet Communication

Positions of the Ethernet communication ports are shown in the figure below.




figure 5-15 Communication Ports

# table 5-4 Port Description

Name	Description
NET1	Connected to LC (the internal wiring has been completed)
NET2	Connected to EMS (the internal wiring has been completed) or
	reserved
NET3	Used for inter-cabinet networking
NET4	Used for inter-cabinet networking

System Manual 5 Electrical Connection



The system supports up to 10 ESS cabinets in parallel. The cabinet with an EMS is accessed to the customer network and connected hand-in-hand with other cabinets that do not have EMS.



- Users can check the label on the power distribution box to understand whether the product is equipped with an EMS controller.
- NET3 and NET4 are used for inter-cabinet networking and no distinction is made between them.

figure 5-16 Inter-cabinet Networking

# 5.10 Post-wiring Work

Inspect the wirings thoroughly and carefully after all electrical connections have been completed. In addition, perform the following operations:

- Check that there is no obstruction or blockage by foreign objects at the air inlet and outlet.
- Seal off the cable inlet and outlet of the ESS cabinet, by filling the gap around them with fire-/water-stop materials.

## **M** WARNING

- · Moisture may get in if the product is not properly sealed.
- · Rodents may get in if the product is not properly sealed.

#### Lock the cabinet door

- **Step 1** Mount back the protective cover for the wiring area, by completing the steps for removal (see "Open Cabinet Door") in reverse.
- Step 2 Lock the cabinet door and pull out the key.
  - - End

# **NOTICE**

After closing the cabinet door, make sure the sealing strip around the door does not curl.

# **6 Battery Connection**

# 6.1 Precautions

Always follow the safety instructions in this manual. In order to avoid personal injury and property damage that may occur during installation or operation, and extend the service life of this product, please carefully read all safety instructions.

Improper or incorrect use may result in:

- A threat to the life and personal safety of the operator or third parties;
- Damage to the energy storage system or other property of the operator or third party.



- The safety precautions in this manual do not cover all specifications to be followed, and all operations should be performed based on the site conditions.
- SUNGROW shall not be liable for any loss arising from failure to follow the safety precautions in the manual.

### **▲** WARNING

- While installing the device with hazardous voltage, follow relevant regulations and local installation safety guidelines.
- Please observe the regulations on the correct use of tools and personal protective equipment.
- All connections must be carried out with distinctive guidance. Any guess and ambiguous attempts must be prohibited.
- Tools with an insulating protective coating must be used.
- Connecting cables should meet the voltage and current requirements.
- All connectors must be safe and reliable to avoid loosening or virtual contact. They must be corrosion-resistant, wear-resistant and shock-proof.
- All connections must comply with the requirements of relevant national standards to prevent arc discharge in any form.
- The connections of internal batteries must be equipped with anti-vibration and antiloosening devices. Temperature, voltage and current sensors must be connected safely and reliably, to prevent loosening, ageing and extrusion. All sensor cables must be free of metal exposure.
- Any type of short circuit should be prevented in the connection process.
- Operators must use this product with personal protective equipment.

System Manual 6 Battery Connection

• All connections must be carried out with distinctive guidance. Any guess and ambiguous attempts must be prohibited.

- Key connections must be correct, reliable (without loosening) and in good contact, without short-circuits.
- All the finished connections must be measured and confirmed one by one.
- All connections must not be in contact with the casing or other components or shortcircuited.
- If there are other uncertain factors, please consult the after-sales technicians of SUN-GROW before any operation.

# 6.2 Battery Wiring

#### **Tools**



figure 6-1 Installation Tools

**Step 1** Before connecting the power cable, put on insulated shoes and safety gloves. Before connecting the power cable between PACKs, disconnect the wiring between the PACK and the S/G first.

6 Battery Connection System Manual

**Step 2** Install the fuse. Open the cabinet door, and remove the sponge separators that hold the fuse plugs.




figure 6-2 Position of Fuse

Step 3 Insert the plugs that come with the fuse into the PACK bases properly.




figure 6-3 Insert Fuse Plugs into PACK Bases

# **MARNING**

When the aviation plug is connected in place, you will hear a "click". Please make sure the connection is secure.



- Insert the positive aviation plug into the positive on the PACK base, and the
  negative plug into the negative on the base. Orange indicates positive, and
  black indicates negative. When the aviation plug is connected in place, you will
  hear a "click".
- When connecting the power cables, you can adjust the position of the fuse properly.

System Manual 6 Battery Connection

**Step 4** Connect the power cables between the PCAKs. The positive connector of the power cable between the PACKs has been secured on the RACK, and the negative connector is secured on the side bracket with the quick-connect clip and cable tie.

# **MARNING**

When the aviation plug is connected in place, you will hear a "click". Please make sure the connection is secure.

## **NOTICE**

When connecting the power cable between the PACKs, take down the negative connector of the power cable from the quick-connect clip on the side bracket, and then insert it into the negative on the base.




figure 6-4 Quick-connect Clip

- 1 Connect the BAT- of Rack1–1 to the BAT+ of Rack1–2;
- 2 Connect the BAT- of Rack1-2 to the BAT+ of Rack1-3.
- 3 Connect the BAT- of Rack2-1 to the BAT+ of Rack2-2;
- 4 Connect the BAT- of Rack2-2 to the BAT+ of Rack2-3.

6 Battery Connection System Manual

**Step 5** Connect the power cable between the PACK and the PCS:

- 1 Connect the BAT+ of Rack1-1 to the BAT1+ of S/G;
- 2 Connect the BAT- of Rack1-4 to the BAT1- of S/G.
- 3 Connect the BAT+ of Rack2-1 to the BAT2+ of S/G;
- 4 Connect the BAT- of Rack2-4 to the BAT2- of S/G.




figure 6-5 PACK Wiring Diagram

# **MARNING**

When the aviation plug is connected in place, you will hear a "click". Please make sure the connection is secure.

- - End

# 7 Powering up and Shutdown

# 7.1 Powering up

# **MARNING**

• The equipment can only be put into operation after confirmation by a professional and approval of the local energy department.

## **▲** WARNING

For equipment that has a long shutdown time, inspect it thoroughly and carefully and make sure all the indicators meet the relevant requirements before powering up.

# 7.1.1 Inspection Before Powering up

Before powering up the equipment, check the following items carefully.

- · Check whether the wiring is correct.
- Check whether the protective covers inside the equipment are installed firmly.
- · Check whether the emergency stop button is released.
- · Check and ensure that there is no grounding fault.
- Check whether the AC and DC voltages meet startup conditions and ensure that there is no over-voltage with a multimeter.
- Check and ensure that no tools or components are left inside the equipment.
- Check all air inlets and outlets for blockage.
- If the equipment has been stored for more than six months, the top radiator fan should be checked for proper rotation, noise or stalling before powering up.

## 7.1.2 Powering on Steps

Inspect the equipment thoroughly before powering it on. The equipment can only be powered on after all the inspection items are confirmed to meet the requirements.

- The power and communication wiring of the ESS have been completed.
- The outdoor temperature is in the range of -30°C to 50°C.



It is not recommended to power on the equipment at temperatures below -30° C. If the temperature is too low, it will take 24 hours or more for the system to heat the cells. During this period, the system cannot operate normally.

**Step 1** Power up the transformer cabinet.(Not configured please skip this step.)

- 1 Close the moulded case circuit breaker QF2 (AC MAIN SWITCH 1#) and completion of the closure of the ESS side switch.
- 2 Close the moulded case circuit breaker QF1 (AC MAIN SWITCH 2#) and completion of the closure of the load/grid side switch.
- 3 Close the switch QS1 (AC FAN), completion of AC supply to the fan.



Transformer cabinet is optional.

## Step 2 Power up the ESS cabinet.

- 1 Turn on the power switch of the S/G (DC SWITCH1~2).
- 2 PCS: Set the DC switch of the PCS to "ON". Make sure the emergency stop button on the cabinet is in the reset state.
- 3 Turn on the QF1 (AC MAIN SWITCH) on the panel to power the AC side of the system.
- 4 Turn on the Q1 (AC AUX SWITCH) on the panel to power on the auxiliary power supply.
- 5 Turn on the Q2 (UPS SWITCH) on the panel, and press the power button on the UPS. The system auxiliary power supply will start working (the switch, LC, fans, and other devices have all been powered on).
- 6 Start up the system through the control software.

#### NOTICE

If the cabinet is equipped with a liquid cooling unit, check the status of the circuit breakers inside the liquid cooling unit. Close the circuit breaker that has not been closed.

- - End

## 7.2 Shutdown

### 7.2.1 Planned Shutdown

Planned shutdown refers to an interruption to the equipment operation that is scheduled in advance for overhaul, test, or maintenance.

Shut the system down via the control software, and switch off the battery relay (in case of an emergency, you can press the emergency stop button on the cabinet).

**Step 1** Preparation for powering off: Shut down the system via the control software (in case of an emergency, you can press the emergency stop button on the cabinet).

### Step 2 Power down the ESS cabinet.

- 1 Turn off the UPS. Turn off the Q2 (UPS SWITCH) on the panel.
- 2 Turn off the Q1 (AC AUX SWITCH) on the panel.
- 3 Turn off the QF1 (AC MAIN SWITCH) on the panel.
- 4 Rotate the PCS DC switch to "OFF".

## **▲** DANGER

Before working on the AC wiring terminals, be sure to turn off the upstream switches of the ESS first.

5 Turn off the power switch of the S/G (DC SWITCH1~2).

**Step 3** Power down the transformer cabinet.(Not configured please skip this step.)

- 1 Disconnect the fan switch QS1 (AC FAN).
- 2 Disconnect the moulded case circuit breaker QF1 (AC MAIN SWITCH 2#).
- 3 Disconnect the moulded case circuit breaker QF2 (AC MAIN SWITCH 1#).

#### - - Fnd

Test the voltage after the system self-discharge is completed.

# 7.2.2 Emergency Shutdown

Contact the local fire department in case of an emergency.

# **8 Fire Suppression**

# 8.1 General Rules

Please comply with the fire laws and regulations of the country/region where the project is located.

Perform regular inspection and maintenance on the fire suppression system regularly to ensure it can function properly.

# 8.2 Fire Suppression System

The FSS scheme for the energy storage system mainly revolves around fire detection and alarm, as well as fire extinguishing. It includes three subsystems: the detection and alarm system, the fire extinguishing system, and the backup system.

#### **FSS Devices**

The specific components and configuration of the FSS are illustrated in the figure and table below.




figure 8-1 FSS Composition

### Layout of FSS

The flammable gas detector, the smoke detector, the heat detector, and the alarm sounder are positioned in the top on the left side of the outdoor cabinet. The temperature-controlled aerosol is located on the inside of the left door panel of the outdoor cabinet. The water pipeline is installed at the middle of the battery compartment, the sprinkler is installed at the top of the water pipeline, and the water pipeline interface is located at the front bottom on the left side of the outdoor cabinet. Please refer to the following figure for further details.

System Manual 8 Fire Suppression




figure 8-2 Layout of FSS

## NOTICE

To ensure its accuracy, the detector should be tested for functionality and calibrated every six months. If the detector fails the test, investigate the cause, and calibrate or replace the detector if necessary.

## 8.3 Device Introduction

# 8.3.1 Fire Detection and Alarm System

The fire detection and alarm system is able to discover fires early in their development and thus helps to reduce the risk of fires to the minimum.

Each ESS cabinet is equipped with a flammable gas detector, a smoke detector, a heat detector, and an alarm sounder, which together constitute the detection and alarm system.

- The flammable gas detector can detect the concentration of flammable gases such as hydrogen. When the flammable gas detector detects that hydrogen concentration in the battery compartment reaches the set threshold (10% LEL), it will send an alarm signal to LC.
- The smoke detector can judge the smoke concentration by measuring the scattering effect of smoke on light. When the smoke detector detects that the smoke concentration in the battery compartment reaches the set threshold (0.15 dB/m), it will send an alarm signal to LC.
- The heat detector can detect temperature changes in the battery compartment. When the heat detector detects that the temperature in the battery compartment reaches the set threshold (54°C), it will send an alarm signal to LC.

8 Fire Suppression System Manual

 In addition, if the LC receives any alarm signal from the flammable gas detector, the smoke detector, or the heat detector, and also receives the over-temperature fault signal of the cell, it will start the alarm sounder, triggering an acoustic alarm to remind the personnel on field about equipment anomaly.

#### NOTICE

When the product leaves the factory, the alarm sounder is off by default. If required, it can be turned on manually on site.




figure 8-3 Control logic of Detection and Alarm System

# 8.3.2 Fire Extinguishing System

The ESS is equipped with an aerosol fire extinguishing system.

The fire extinguishing system is an aerosol fire extinguishing system, which includes fire extinguishing agent (temperature-controlled aerosol), a fire extinguishing agent tank, a temperature sensor and a signal feedback device. Each outdoor cabinet is provided with a fire extinguishing agent tank containing aerosol, a temperature sensor, and a signal feedback device.

When the temperature sensor detects that the temperature in the battery compartment reaches 93°C, the aerosol will be automatically released into the battery compartment to extinguish the fire. After the aerosol is released, the signal feedback device sends the fire extinguishing agent release signal to LC.

System Manual 8 Fire Suppression

## **NOTICE**

In addition, if LC also receives an over-temperature fault signal from the cell, it will shut down the corresponding outdoor cabinet.

The effective space volume for the outdoor cabinet is 3.72 m<sup>3</sup>, while the aerosol fire extinguishing system contains 500 g aerosol extinguishing agent, which covers an effective space volume of 6.3m<sup>3</sup>, meeting the fire extinguishing requirements.




figure 8-4 Control logic of Fire Extinguishing System

# 8.3.3 Backup Protection System

In addition to the fire extinguishing system, the ESS also has a backup protection system, in case the fire keeps spreading even after the fire extinguishing system has acted.

After the fire extinguishing system acts, if the fire continues to spread, the customer can use the backup system to extinguish the fire after the ESS is powered off. The backup system mainly includes sprinklers, water pipelines and water pipeline interfaces.

- Each ESS cabinet is equipped with two sprinklers, a water pipeline, and a water pipeline interface.
- The sprinkler is an upright and closed type. When the temperature around the sprinkler reaches 93°C, the glass ball of the sprinkler automatically breaks and the sprinkler acts.

8 Fire Suppression System Manual

Water flows into the battery compartment through pipelines inside and outside the ESS cabinet, and submerges the battery Pack in the battery compartment, thus cooling the cabinet and extinguishing the fire.

 The water pipeline and pipeline interface are galvanized steel pipes with a diameter of DN25. The water pipeline and pipeline interface have been installed before they leave the factory. The pipelines outside of the ESS cabinets need to be designed and installed by customers and connected with the pipeline interfaces in ESS cabinets.

## NOTICE

The water pressure at the inlet of the water pipeline interface shall not be less than 0.101 MPa, and the total flow rate shall not be less than 114.73 L/min.




figure 8-5 Control logic of Backup System

# 9 Troubleshooting

In case of anything abnormal with the ESS, it is suggested to perform troubleshooting by referring to the troubleshooting methods mentioned in the LC300 user manual first.

For more information, please refer to the below documents:



If the problem persists or there are any other questions, please contact SUNGROW. It would be helpful if you could provide the below information:

- · Model and S/N of the ESS and its internal device;
- · Fault information and a brief description of the fault;
- A photo of the fault, if possible.

# 10 Routine Maintenance

# 10.1 Precautions Before Maintenance

### **▲** WARNING

- Do not open the door to maintain the device in rainy, humid or windy days. SUN-GROW shall not be held liable for any damage caused by violation of the warning.
- Avoid opening the container door when the humidity is high in rain, snow or fog, and make sure that the seals around the container door do not curl when the door is closed.

# **M** WARNING

- To avoid electric shock, do not perform any other maintenance operations beyond this manual.
- If necessary, contact SUNGROW customer service for maintenance.

## **NOTICE**

In the event of heavy snowfall at the project site, please clear the snow from the top of the equipment and the surrounding area in a timely manner.



In fair weather, it is recommended to open the container door to dehumidify the equipment.

# 10.2 Liquid Cooling System Maintenance

The recommended maintenance intervals are listed below, which however may need to be adjusted based on the installation environments of the product.

The maintenance interval of the product is subject to factors like plant size, installation position, and on-site environment. For the equipment working in sandy or dusty environments, it is necessary to shorten the interval and increase the frequency of maintenance.

Item	Content	Inspection Method	Mainte- nance tools
Fans	Check whether the fan blades can rotate properly and are free of damage. If not, replace the fan.	1. The fan blade rotates smoothly without making abnormal noise; 2. There is no damage to the fan blade. Note: This inspection should be performed at least once every six months. Damage inspection is not mandatory.	Screwdriv- er with long handle
Water pump	1. Check whether an area of over 5% of the air intake hole for heat dissipation on the water pump is blocked. If so, clear the blockage with a brush; 2. Inspect the pump body (not the pipe joining points) visually, and see if there is visible dripping (except condensation). If so, replace the sealing ring of the pump.	1. The water pump operates smoothly without making abnormal noise; 2. There is no visible dripping on the pump body (except condensation).	Brush
Water system	Check whether the HMI of the liquid cooling unit reports an alarm.	Check if the unit reports a "water level too low" alarm. Refill coolant into the water tank if the alarm is reported.	Slotted screwdriver, Phillips screwdriver, water pump, water pipe, clamp

# 10.3 Container Maintenance

# 10.3.1 Appearance Repair



Check if the protective paint sprayed on the enclosure of the product fell off or peeled off. If so, repair it timely.

Spray a special protective paint to the exterior of the product every 5 years.

10 Routine Maintenance System Manual

#### **Solutions**

Select different repair solutions based on the damage conditions.

Conditions	Solutions
Surface dirt that can be wiped off	"10.3.1.1 Detergent Cleaning"
Finish paint falls off, and the primer is intact	"10.3.1.2 Finish Paint Repair"
Primer is damaged, and the base material is	"10.3.1.3 Double-Layer Paint Repair"
exposed	

## 10.3.1.1 Detergent Cleaning

For dust or stains on the product surface, you can wipe them off using water and alcohol.

# **Prepared by Users**

table 10-1 Cleaning Tools

No.	Item
1	Cleaning cloth
2	Water
3	Alcohol or other non-corrosive detergents

- **Step 1** Wet the cleaning cloth (or other scrubbing tools) with water, and scrub the dirty parts on the surface.
- **Step 2** If the dirt cannot be cleaned with water, scrub with 97% alcohol till the surface is acceptable. (Or try to use non-corrosive detergents that are generally used locally.)



#### --End

### 10.3.1.2 Finish Paint Repair

For minor scratches or surface paint chalking, where the finish paint has peeled off, but the base material is not exposed, finish paint repair is needed to restore the product appearance.

### **Finish Paint Selection and Mixing**

table 10-2 Finish Paint Selection and Mixing

Brand and Model	Chemical Component	Mixing Ratio	Thinner	Drying Time (Minimum)
Jotun Finish	Tue semenant	Main agent and the		5°C 24h
Coat	Two-component chemically cured	Main component : Hardener= 10:1	Jotun Thinner	10°C 12h
Hardtop XP or	aliphatic	(Volume Ratio)	No.10	23°C 5h
Hardtop XPL	'	,		40°C 3h
AkzoNobel	Two-component	Main component	International	5°C 24h
Finish Paint	acrylic polyur-	: Hardener= 6:1	International GTA056	25°C 6h
Interthane 990	ethane paint	(Volume Ratio)	C 17 (000	35°C 4h

• Confirm with SUNGROW before using paints of other brands or models.



- When using a two-component paint, first thoroughly agitate each component individually, and then mix them in the specified proportions for stirring.
- Add the thinner only after the paint and hardener have been mixed.
- Do not use paint that has exceeded its shelf life.

# **Prepared by Users**

table 10-3 Cleaning Tools

No.	Item
1	400 mesh/600 abrasive paper
2	Cleaning cloth
3	Alcohol
4	Brush
5	Finish paint
6	Film thickness meter

# **Environment Requirements**

• Ambient temperature: 5°C-40°C

Base material temperature: 5°C–60°C

Relative humidity: 10%–85%RH

## **Repair Steps**

**Step 1** Polish the paint surface with blistering or scratches with an abrasive paper to expose the gray primer. Use a film thickness meter to measure the primer thickness, which must be at least 150µm.



10 Routine Maintenance System Manual

Step 2 Use a clean brush to remove any residue from the surface.

**Step 3** Use a piece of clean cloth dipped in alcohol or detergent to remove the surface powder.








Step 4 Repair the finish paint.

1 Prepare the finish paint with the same color as the appearance.



- 2 Mix the finish paint according to the paint model and the requirements of "table 10-2 Finish Paint Selection and Mixing".
- 3 Apply the finish paint using a brush in a crosshatch pattern. Once the paint fully dried, measure the film thickness using a film thickness meter. Ensure that the single coat thickness falls between  $50\mu m-100\mu m$ .



4 When applying multiple layers of paint, wait for each layer to dry completely before applying the next. The total thickness of the primer and finish paint must be at least 240µm.

**Step 5** Inspect the paint to ensure it has a uniform color, smooth transitions, and meets the required film thickness.

#### - - End

# 10.3.1.3 Double-Layer Paint Repair

If the rusted area is large, or there are deep scratches or dents that expose the base material, perform a double-layer paint repair, including both a primer and a finish paint.

## **Primer and Finish Paint Selection and Mixing**

table 10-4 Primer and Finish Paint Selection and Mixing

Brand and model	Chemical Component	Mixing Ratio	Thinner	Drying Time (Minimum)
Jotun Primer Jotamastic 90	Two-component epoxy paint	Main component : Hardener= 3.5:1 (Volume Ratio)	Jotun Thin- ner No.17	5°C 30h 10°C 10h 23°C 3h 40°C 1.5h
AkzoNobel Primer Interseal 670HS	Two-component epoxy paint	Main component : Hardener= 5.67:1 (Volume Ratio)	International GTA220	5°C 36h 10°C 16h 25°C 10h 40°C 4h
Jotun Finish Coat Hardtop XP or Hardtop XPL	Two-component chemically cured aliphatic	Main component : Hardener= 10:1 (Volume Ratio)	Jotun Thin- ner No.10	5°C 24h 10°C 12h 23°C 5h 40°C 3h
AkzoNobel Finish Paint Interthane 990	Two-component acrylic polyur-ethane paint	Main component : Hardener= 6:1 (Volume Ratio)	International GTA056	5°C 24h 25°C 6h 35°C 4h



- Use primers and finish paints from the same manufacturer.
- Confirm with SUNGROW before using any paint from a different manufacturer.



- When using a two-component paint, first thoroughly agitate each component individually, and then mix them in the specified proportions for stirring.
- Add the thinner only after the paint and hardener have been mixed.
- · Do not use paint that has exceeded its shelf life.

10 Routine Maintenance System Manual

### Prepared by users

table 10-5 Cleaning Tools

No.	Item
1	400 mesh/600 mesh abrasive paper
2	Cleaning cloth
3	Alcohol
4	Brushes with different sizes
5	Grinder (conical and cylindrical polishing heads)
6	Wall putty
7	Finish coat
8	Primer
9	Film thickness meter

# **Environment Requirements**

• Ambient temperature: 5°C-40°C

Base material temperature: 5°C–60°C

Relative humidity: 10%RH–85%RH

# **Repair Steps**

**Step 1** Use a grinder or abrasive paper to smooth uneven areas on the surface, achieving a smooth finish with a metallic luster. Ensure a uniform transition from rusted areas to intact coating.




Uneven areas refer to burrs, metal fragments, slag, gaps, and sharp edges on the product.

**Step 2** For deeper defects such as scratches or dents, repair them with wall putty to ensure a flat surface.


**Step 3** Use a clean brush to remove any residue from the surface.

Step 4 Use a piece of clean cloth dipped in alcohol to remove the surface powder.



Step 5 Repair the primer.

1 Prepare the primer with the same color as the appearance.



- 2 Mix the primer according to the paint model and the requirements of "table 10-4 Primer and Finish Paint Selection and Mixing".
- 3 Apply a primer with a small brush, and use a film thickness meter to ensure the coating thickness in corners and gaps is between 70μm–80μm.
- 4 After the first layer dries, apply another layer of primer using a brush in a crosshatch pattern. Once it is dry, check that the dry film thickness is within  $100\mu m-300\mu m$ .

Step 6 Refer to "10.3.1.2 Finish Paint Repair" for finish paint repair.

**Step 7** Inspect the paint to ensure it has a uniform color, smooth transitions, and meets the required film thickness.

--End

10 Routine Maintenance System Manual

When using spray paint, follow these steps:



- 1 Carefully cover the area outside the damaged spot (extending 800mm outward) using masking paper.
- 2 Spray the exposed area with the paint. After the paint dries, check that the dry film thickness is within the range of 100μm–300μm.

# 10.3.2 Checking Door Locks and Hinges

Check whether the door locks and hinges of the container can be used normally after cleaning. Lubricate the door lock holes and hinges properly when necessary.

# 10.3.3 Checking Sealing Strips

If the sealing strip is in good condition, it can effectively prevent water seepage inside the container. Therefore, carefully check the sealing strip and replace it immediately if there is any damage.

# 10.4 Battery Maintenance

### 10.4.1 Maintenance Precautions

# **M** WARNING

Do not leave the product in a low voltage or low SOC condition for a long period of time. Loss of capacity due to the following conditions is not covered by the warranty.

- · Battery discharge cell voltage is below 2.7V for 120 consecutive hours.
- Any cell cluster SOC is 0% for 120 consecutive hours.
- Battery discharge cell voltage ≤2V.



### NOTICE

 In order to avoid triggering the warranty expiration condition, when the "Cell Under-voltage Fault" or "Cell Over-voltage Fault" is triggered, the user must contact the local team of Sungrow within 24 hours and follow the requirements of Sungrow to carry out the next operation.

• If the system is configured with the "Active power up" function, When ESS minimum rack SOC reaches the threshold for this function (the threshold can be set from 0 to the lower SOC protection value, and the threshold does not exceed 5% SOC), the system will charge the battery with low power until the SOC reaches a safe threshold (5% SOC) automatically, The recharging power can be set within the range of 100 kW to 150 kW. During Active power up, when the EMS issues a charging instruction, the LC controller will prioritize the EMS charging instruction. When the EMS issues a discharging instruction, the LC controller will respond according to the specific system SOC value. Sungrow will enable this function by default when the device is shipped from the factory, In order to minimize the risk of under-voltage of the battery that may void the warranty, Sungrow recommends that users do not turn off the "Active power up" function.

### **NOTICE**

- If the system will not be in operation for an extended period (7 days or more), it's recommended to increase the SOC lower limit protection value to above 10% SOC. Additionally, it is important to regularly monitor the system's SOC to avoid the risk of over discharge which will cause warranty expiration.
- During maintenance or shutdown, if the SOC of any battery cluster is 0%, the SOC needs to be charged to 15% and above within 120 hours.
- If the SOC of any battery cluster is 0% during operation, the SOC needs to be charged to 5% and above within 2 hours. Or when the SOC reaches 0%, a command can be issued by the host computer EMS to change the system mode to recharge mode.
- If the system is stored for a long period of time (six months or more) without operation, the system needs to do at least 1 full charge in order to activate the battery before the system is used for the first time.

For safe and efficient maintenance of the system, maintenance personnel must carefully read and observe the following safety requirements:

- 1 Have the electrician certificate issued by the Work Safety Supervision Bureau, and receive professional training before assuming their work.
- 2 Follow relevant safety precautions, use necessary tools, and wear personal protective equipment.
- 3 Do not wear metal accessories such as jewelry or watches.



10 Routine Maintenance System Manual

4 Never touch the high-voltage positive and negative electrodes of the energy storage system by both hands at the same time under all circumstances.

- 5 Prior to the maintenance of the energy storage system, disconnect all high-voltage and low-voltage switches.
- 6 Do not clean this product directly with water. If necessary, use the vacuum cleaner to clean it.
- 7 Plug and remove cables in accordance with the specifications, without brute force or violent operation.
- 8 After maintenance is completed, clean tools and materials in time and check whether there are metal objects left inside or at the top of the product.
- 9 In case of any doubt on operation and maintenance of this product, contact the Customer Service Center of SUNGROW instead of operation without permission.

#### 10.4.2 Maintenance

- 1 PACK operating temperature: The working temperature should be kept between -30°C 50°C. The temperature charging and discharging should be 15°C 30°C and typically 25°C.
- 2 The RACK should not be charged or discharged with high magnifying power. The continuous charging and discharging current of a single rack should not exceed the rated current.
- When the energy storage system is not used in a long time, it should be charged once every six months, until its SOC is 30%–40%.
- 4 When the system is used after long-term storage, it should be fully charged at least once to restore the best performance of the battery.
- 5 Regularly check whether the air duct of the cooling system is blocked and clean the system. In particular, clean the air inlet and outlet of the fan and use a vacuum cleaner if necessary, to maintain free air circulation inside the cabinet. Before dust removal, the power supply must be cut off. It is forbidden to rinse the system with water.
- 6 Regularly check whether the fastening bolts of the high-voltage cables and connecting busbars of the energy storage system are loose, whether the contacts are in good conditions, and whether the terminal surfaces are severely corroded or oxidized.
- 7 Regularly check the protective covers of high-voltage positive and negative electrodes of the PACK for ageing, damage and missing.
- 8 Regularly check cables for loosening, ageing, damage and fracture and inspect whether the insulation is in good conditions.
- 9 Regularly check the battery container for pungent odor and high-voltage connections for burning odor.
- 10 Regularly check whether the voltage, temperature and other data of the monitoring upper computer are correct and whether there are fault alarms in the alarm column.
- 11 Regularly check whether the status and alarm indicators of the energy storage system are in good conditions and whether they work properly.

12 Regularly check whether the emergency stop button of the energy storage system can be used, in order to quickly shut down the system in an emergency.

- 13 Regularly check whether the fire extinguishers are in good conditions and within the validity period.
- 14 Never use different types of battery modules in series or parallel.
- 15 PACK A and PACK B are prohibited from replacing each other.

### **⚠** WARNING

- The battery is potentially dangerous, so appropriate protective measures must be taken during operation and maintenance!
- Incorrect operation may cause severe personal injury and property damage!
- · Use the appropriate tools and protective equipment during battery operation.
- Battery maintenance must be performed by those who have battery expertise and received safety training.

# 10.5 Coolant Replacement

Object	Standard	Period	Tools
Coolant	<ol> <li>There are obvious impurities in antifreeze;</li> <li>Antifreeze is significantly darker in color.</li> </ol>	5–6 years	Water pump, hose, hose clamp, slot- ted screwdriver  Note: Please contact Sungrow Cus- tomer Service to replace hardware facilities

## **M** WARNING

Normally coolant is not a health hazard, excessive exposure may cause irritation to the eyes, skin and breathing.

### **NOTICE**

- The coolant in the refill tank must not exceed the "H" line.
- The brand of coolant to be replaced is limited to Great Wall and Acwell, and it is recommended to use the same brand of coolant. If you choose to mix Great Wall and Acwell coolants, the mixing ratio of different coolants is limited to 9:1.

### Personal protection

Wear personal protective equipment (PPE) when changing coolant. PPE should comply with relevant national standards, including but not limited to the following protective equipment.

10 Routine Maintenance System Manual

Protective parts	Protective equipment
Respiratory protection	Under normal conditions of use, it is generally not necessary to wear respiratory protection equipment. If the engineering control facility does not maintain the air concentration at a level sufficient to protect the health of personnel, choose respiratory protection equipment suitable for the conditions of use and in compliance with relevant legal requirements. If you need to wear a safety filter mask, please choose a suitable mask and filter combination. Choose a filter suitable for a mixture of particulate/organic gas
Handa nucta stica	and vapor [boiling point >65 °C (149 °F)].
Hands protection	Use oil-resistant, chemical-resistant protective gloves.
Eyes protection	Please use protective goggles.
Skin and body protection	Use non-permeable protective clothing and safety shoes.

# **Disposal considerations**

Waste types	Disposal measures
	Discharges are made in accordance with local regulations and
Coolant	are not disposed of haphazardly.
Dubbish remands	Separate and recycle, and if it meets the relevant regulations, it
Rubbish remnant	can be burned or reused.
	Dispose of in accordance with all applicable local and national
	regulations. Use recovery/recycling where feasible, otherwise in-
	cineration is the recommended method of disposal. Empty con-
	tainers may contain hazardous residues. Do not cut, puncture or
Containers	weld on or near to the container. Labels should not be removed
Containers	from containers until they have been cleaned. Contaminated con-
	tainers must not be treated as household waste. Containers
	should be cleaned by appropriate methods and then re-used or
	disposed of by landfill or incineration as appropriate. Do not incin-
	erate closed containers.

## Accidental release measures

When a coolant leak occurs, refer to the following measures to deal with it.

- Immediately contact a professional to have uninvolved persons evacuated quickly to safety.
- Cut off the source of the spill as far as possible and prevent it from entering spaces such as sewers, drains and bodies of water.
- When cleaning up spilled liquids, wear protective equipment to protect your body from contact with the spilled or released material.

 Use sand, mud or other materials that can be used as barriers to set up barriers to prevent diffusion. Recover liquid directly or store in absorbent. Clean the contaminated area with detergent, water and a hard broom. Put the collected liquid in a disposable container.

# First aid measures

Contact method	Measures
Inhalation	Move to fresh air. If breathing has stopped, give artificial respiration
Inhalation	first aid. Seek medical attention.
Ckin contact	Take off contaminated clothing. Rinse the skin thoroughly with soap
Skin contact	and water. Seek medical attention if skin inflammation or rash occurs.
Eyes contact	Flush eyes with plenty of water for at least 15 minutes. Seek medical
	attention.
	If ingested, but conscious, water or milk to drink and actively seek
	medical help, do not induce vomiting unless instructed by healthcare
Ingestion	patients. If you cannot get help from a doctor, please send the patient
	and the container and label to the nearest medical emergency center
	or hospital. Do not give any food to unconscious patients.



# 11 Appendix

# 11.1 Abbreviations

Abbreviation	Definition
В	
ВМ	Battery Module (or PACK)
ВС	Battery Cluster (or RACK)
BMU	Battery Management Unit
BCMU (CMU)	Battery Cluster Management Unit (CMU for short)
BSMU (SMU)	Battery System Management Unit (SMU for short)
BMS	Battery Management System
BSC	Battery System Controller
ВСР	Battery Collection Panel. Battery DC inputs are combined into the BCP DC copper bar, and connected to the PCS DC side through the copper bar on the other side of the BCP.
BSP	Battery Power Supply Panel. It is used as an auxiliary power supply for the components inside the battery, such as lighting, FSS, etc.
D	
DC/DC	DC/DC Converter
L	
LC	Local Controller
Р	
PCS	Power Conversion System
S	
SCADA	Supervisory Control and Data Acquisition System
S/G	Switch Gear
SOC	State Of Charge
SOH	State Of Health

System Manual 11 Appendix

# 11.2 Technical Data

DC Side         LFP 3.2 V / 280 Ah           System battery configuration         25682P           Nominal capacity         458 kWh           Nominal voltage range         691.2V−934.4V           AC side (on-grid)         110kW           Nominal power         110kW           Nominal voltage         400 V           Voltage range         340 V ~ 440 V           Nominal frequency         50 Hz / 60 Hz           Frequency range         45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz           Max.THD of current         < 3 % (Nominal power)           DC component         < 0.5 % (Nominal power)           Power factor range         1.0 leading ~ 1.0 lagging           AC side (off-grid) *         Nominal voltage           Nominal voltage         400 V           Nominal frequency         50 Hz / 60 Hz           Max.THD of voltage         < 3 % (Linear load)           Unbalance load capacity         100 %           System Parameters         Dimensions (Width * Height * Depth)         2152 mm * 2470 mm * 1610 mm           'Weight         Approx. 5300 kg           Degree of protection         IP55           Internal power supply (Default) External power supply (Optional)           External power supply (Optional)           C5 (Default	Product Model	ST455kWH-110kW-4h		
System battery configuration  256S2P  Nominal capacity  458 kWh  Nominal voltage range  691.2V–934.4V  AC side (on-grid)  Nominal power  110kW  Nominal voltage  400 V  Voltage range  340 V ~ 440 V  Nominal frequency  50 Hz / 60 Hz  Frequency range  45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current  C omponent  C one factor range  1.0 leading ~ 1.0 lagging  AC side (off-grid)*  Nominal voltage  400 V  Nominal frequency  50 Hz / 60 Hz  ANA.THD of voltage  400 V  Nominal voltage  400 V  Nominal voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Max.THD of voltage  43 % ( Linear load )  Unbalance load capacity  100 %  System Parameters  Dimensions (Width * Height * Depth)  2152 mm * 2470 mm * 1610 mm  *Weight  Approx. 5300 kg  Degree of protection  IP55  Auxiliary power supply  Anti-corrosion degree  C3 ( Optional )  C5 ( Default )  External power supply ( Optional )  C5 ( Default )  C3 ( Optional )  Operation humidity range	DC Side			
Nominal capacity  A58 kWh  Nominal voltage range  691.2V-934.4V  AC side (on-grid)  Nominal power  110kW  Nominal voltage  400 V  Voltage range  340 V ~ 440 V  Nominal frequency  50 Hz / 60 Hz  Frequency range  45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current  C 3 % (Nominal power)  Power factor range  1.0 leading ~ 1.0 lagging  AC side (off-grid) *  Nominal voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Amx.THD of voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Wax.THD of voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Max.THD of voltage  43 % (Linear load)  Unbalance load capacity  100 %  System Parameters  Dimensions (Width * Height * Depth)  2152 mm * 2470 mm * 1610 mm  "Weight  Approx. 5300 kg  Degree of protection  IP55  Auxiliary power supply  Anti-corrosion degree  C3 ( Optional )  C5 ( Default )  External power supply ( Optional )  C5 ( Default )  C3 ( Optional )  Operation humidity range	Cell type	LFP 3.2 V / 280 Ah		
Nominal voltage range  AC side (on-grid)  Nominal power  110kW  Nominal voltage  400 V  Voltage range  340 V ~ 440 V  Nominal frequency  50 Hz / 60 Hz  Frequency range  45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current  Component  Component  Component  AC side (off-grid)*  Nominal voltage  400 V  Nominal voltage  400 V  Nominal voltage  400 V  Nominal requency  50 Hz / 60 Hz  Ax.THD of voltage  400 V  Nominal requency  50 Hz / 60 Hz  Max.THD of voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Max.THD of voltage  43 % ( Linear load )  Unbalance load capacity  100 %  System Parameters  Dimensions (Width * Height * Depth)  2152 mm * 2470 mm * 1610 mm  "Weight  Approx. 5300 kg  Degree of protection  IP55  Auxiliary power supply  Anti-corrosion degree  C5 ( Default )  External power supply ( Optional )  C5 ( Default )  C3 ( Optional )  Operation humidity range	System battery configuration	256S2P		
AC side (on-grid)  Nominal power  110kW  Nominal voltage  400 V  Voltage range  340 V ~ 440 V  Nominal frequency  50 Hz / 60 Hz  Frequency range  45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current  Component  Component  AC side (off-grid) *  Nominal voltage  AC side (off-grid) *  Nominal frequency  50 Hz / 60 Hz  Aux.THD of voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Aux.THD of voltage  400 V  System Parameters  Dimensions (Width * Height * Depth)  2152 mm * 2470 mm * 1610 mm  Weight  Approx. 5300 kg  Degree of protection  IP55  Auxiliary power supply  Anti-corrosion degree  C5 ( Default )  C5 ( Default )  C3 ( Optional )  Operation humidity range	Nominal capacity	458 kWh		
Nominal power  Nominal voltage  400 V  Voltage range  340 V ~ 440 V  Nominal frequency  50 Hz / 60 Hz  Frequency range  45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current  Component  Component  Component  Ac side (off-grid) *  Nominal voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Nominal voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Max.THD of voltage  3 % ( Linear load )  Unbalance load capacity  100 %  System Parameters  Dimensions (Width * Height * Depth)  2152 mm * 2470 mm * 1610 mm  Weight  Approx. 5300 kg  Degree of protection  IP55  Auxiliary power supply  Anti-corrosion degree  Component  110kW  400 V  Anti-corrosion degree  10 leading ~ 1.0 lagging  45 Hz ~ 65 Hz  40 V  Nominal power supply ( Default )  External power supply ( Optional )  Component  Component  Component  110kW  400 V  Anti-corrosion degree  1.0 leading ~ 1.0 lagging  1.0 leading ~ 1.0 laggi	Nominal voltage range	691.2V-934.4V		
Voltage range  340 V ~ 440 V  Nominal frequency  50 Hz / 60 Hz  Frequency range  45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current  C 3 % (Nominal power)  Power factor range  1.0 leading ~ 1.0 lagging  AC side (off-grid) *  Nominal voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Max.THD of voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Max.THD of voltage  3 % (Linear load)  Unbalance load capacity  100 %  System Parameters  Dimensions (Width * Height * Depth)  2152 mm * 2470 mm * 1610 mm  *Weight  Approx. 5300 kg  Degree of protection  IP55  Auxiliary power supply  External power supply ( Default )  External power supply ( Optional )  C5 ( Default )  C3 ( Optional )  Operation humidity range	AC side (on-grid)			
Voltage range 340 V ~ 440 V  Nominal frequency 50 Hz / 60 Hz  Frequency range 45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current < 3 % ( Nominal power )  DC component < 0.5 % ( Nominal power )  Power factor range 1.0 leading ~ 1.0 lagging  AC side (off-grid) *  Nominal voltage 400 V  Nominal frequency 50 Hz / 60 Hz  Max.THD of voltage < 3 % ( Linear load )  Unbalance load capacity 100 %  System Parameters  'Dimensions (Width * Height * Depth) 2152 mm * 2470 mm * 1610 mm  'Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply ( Default )  External power supply ( Default )  External power supply ( Optional )  C5 ( Default )  C3 ( Optional )  Operation humidity range 0 % ~ 100 %	Nominal power	110kW		
Nominal frequency 50 Hz / 60 Hz  Frequency range 45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current <3 % (Nominal power)  DC component <0.5 % (Nominal power)  Power factor range 1.0 leading ~ 1.0 lagging  AC side (off-grid) *  Nominal voltage 400 V  Nominal frequency 50 Hz / 60 Hz  Max.THD of voltage <3 % (Linear load)  Unbalance load capacity 100 %  System Parameters  'Dimensions (Width * Height * Depth) 2152 mm * 2470 mm * 1610 mm  'Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply  Anti-corrosion degree C3 (Optional)  C5 (Default)  C3 (Optional)  Operation humidity range 0 % ~ 100 %	Nominal voltage	400 V		
Frequency range 45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz  Max.THD of current < 3 % (Nominal power)  DC component < 0.5 % (Nominal power)  Power factor range 1.0 leading ~ 1.0 lagging  AC side (off-grid) *  Nominal voltage 400 V  Nominal frequency 50 Hz / 60 Hz  Max.THD of voltage < 3 % (Linear load)  Unbalance load capacity 100 %  System Parameters  *Dimensions (Width * Height * Depth) 2152 mm * 2470 mm * 1610 mm  *Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply Internal power supply (Default)  External power supply (Optional)  Anti-corrosion degree C3 (Optional)  Operation humidity range 0 % ~ 100 %	Voltage range	340 V ~ 440 V		
Max.THD of current  Component  Co	Nominal frequency	50 Hz / 60 Hz		
DC component <ul> <li>&lt; 0.5 % (Nominal power)</li> </ul> Power factor range  1.0 leading ~ 1.0 lagging  AC side (off-grid) *  Nominal voltage  400 V  Nominal frequency  50 Hz / 60 Hz  Max.THD of voltage <ul> <li>&lt; 3 % (Linear load)</li> </ul> Unbalance load capacity  100 %  System Parameters  *Dimensions (Width * Height * Depth)  2152 mm * 2470 mm * 1610 mm  *Weight  Approx. 5300 kg  Degree of protection  IP55  Auxiliary power supply  Anti-corrosion degree  C3 ( Default )  External power supply ( Optional )  C5 ( Default )  C3 ( Optional )  Operation humidity range  0 % ~ 100 %	Frequency range	45 Hz ~ 55 Hz / 55 Hz ~ 65 Hz		
Power factor range 1.0 leading ~ 1.0 lagging  AC side (off-grid) *  Nominal voltage 400 V  Nominal frequency 50 Hz / 60 Hz  Max.THD of voltage <3 % ( Linear load )  Unbalance load capacity 100 %  System Parameters  *Dimensions (Width * Height * Depth) 2152 mm * 2470 mm * 1610 mm  *Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply ( Default )  External power supply ( Optional )  Anti-corrosion degree C3 ( Optional )  Operation humidity range 0 % ~ 100 %	Max.THD of current	< 3 % ( Nominal power )		
AC side (off-grid) *  Nominal voltage 400 V  Nominal frequency 50 Hz / 60 Hz  Max.THD of voltage <3 % ( Linear load )  Unbalance load capacity 100 %  System Parameters  *Dimensions (Width * Height * Depth) 2152 mm * 2470 mm * 1610 mm  *Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply Default )  External power supply ( Default )  External power supply ( Optional )  Anti-corrosion degree C3 ( Optional )  Operation humidity range 0 % ~ 100 %	DC component	< 0.5 % ( Nominal power )		
Nominal voltage 400 V  Nominal frequency 50 Hz / 60 Hz  Max.THD of voltage <3 % ( Linear load )  Unbalance load capacity 100 %  System Parameters  *Dimensions (Width * Height * Depth) 2152 mm * 2470 mm * 1610 mm  *Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply ( Default )  External power supply ( Optional )  Anti-corrosion degree C3 ( Optional )  Operation humidity range 0 % ~ 100 %	Power factor range	1.0 leading ~ 1.0 lagging		
Nominal frequency 50 Hz / 60 Hz  Max.THD of voltage <3 % ( Linear load )  Unbalance load capacity 100 %  System Parameters  *Dimensions (Width * Height * Depth) 2152 mm * 2470 mm * 1610 mm  *Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply ( Default ) External power supply ( Optional )  Anti-corrosion degree C5 ( Default ) C3 ( Optional )  Operation humidity range 0 % ~ 100 %	AC side (off-grid) *			
Max.THD of voltage < 3 % ( Linear load )  Unbalance load capacity 100 %  System Parameters  *Dimensions (Width * Height * Depth) 2152 mm * 2470 mm * 1610 mm  *Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply ( Default ) External power supply ( Optional )  Anti-corrosion degree C3 ( Optional )  Operation humidity range 0 % ~ 100 %	Nominal voltage	400 V		
Unbalance load capacity  System Parameters  *Dimensions (Width * Height * Depth)  *Weight  Approx. 5300 kg  Degree of protection  IP55  Auxiliary power supply  Anti-corrosion degree  C5 ( Default )  C3 ( Optional )  Operation humidity range	Nominal frequency	50 Hz / 60 Hz		
*Dimensions (Width * Height * Depth)  *Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply Default (Optional)  Anti-corrosion degree C3 (Optional)  Operation humidity range 0 % ~ 100 %	Max.THD of voltage	< 3 % ( Linear load )		
*Dimensions (Width * Height * Depth)  2152 mm * 2470 mm * 1610 mm  *Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply  Internal power supply ( Default )  External power supply ( Optional )  C5 ( Default )  C3 ( Optional )  Operation humidity range  0 % ~ 100 %	Unbalance load capacity	100 %		
*Weight Approx. 5300 kg  Degree of protection IP55  Auxiliary power supply Default (Default ) External power supply (Optional )  Anti-corrosion degree C3 (Optional )  Operation humidity range 0 % ~ 100 %	System Parameters			
Degree of protection  IP55  Auxiliary power supply  Internal power supply ( Default ) External power supply ( Optional )  C5 ( Default ) C3 ( Optional )  Operation humidity range  0 % ~ 100 %	*Dimensions (Width * Height * Depth)	2152 mm * 2470 mm * 1610 mm		
Auxiliary power supply  Internal power supply ( Default ) External power supply ( Optional )  C5 ( Default ) C3 ( Optional )  Operation humidity range  0 % ~ 100 %	*Weight	Approx. 5300 kg		
Auxiliary power supply  External power supply ( Optional )  C5 ( Default )  C3 ( Optional )  Operation humidity range  0 % ~ 100 %	Degree of protection	IP55		
Anti-corrosion degree  C3 (Optional)  Operation humidity range  0 % ~ 100 %	Auxiliary power supply	,		
	Anti-corrosion degree	,		
Operation temperature range -30 °C ~ 50 °C ( > 45 °C derating )	Operation humidity range	0 % ~ 100 %		
- L - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	Operation temperature range	-30 °C ~ 50 °C ( > 45 °C derating )		

11 Appendix System Manual

Product Model	ST455kWH-110kW-4h		
Max. operating altitude	3000 m		
Temperature control method	Intelligent liquid cooling		
Noise	≤ 70 dB(A) @ 1 m		
Fire suppression system	Default : Flammable gas detector, Smoke detector, Heat detector, Alarm sounder, Aerosol, Sprinkler Optional : Ventilation system		
Communication interface	Ethernet		
Communication protocol	Modbus TCP		
Standard	IEC 62619, IEC 63056, IEC 62040, IEC 62477, IEC 61000, UN 38.3, AS/NZS 4777.2, AS/NZS 3000		
Max.Parallel quantity (off-grid)	10		
Transformer cabinet parameter **			
Transformer capacity	250 kVA		
Primary side voltage / Secondary side voltage	400 V / 400 V ( Dyn11 )		
Nominal frequency	50 Hz / 60 Hz		
Dimensions ( W * H * D )	1200 mm * 2000 mm * 1200 mm		
Weight	1500 kg		
Degree of protection	IP55		
Anti-corrosion degree	C5 ( Default ) C3 ( Optional )		
Operation humidity range	0 % ~ 100 %		
Operation temperature range	-30 °C ~ 50 °C ( > 45 °C derating )		
Max. operating altitude	3000 m		
Temperature control method	Air cooling		
The technical data is for reference only, please refer to the information on the nameplate o			

<sup>\*</sup>The technical data is for reference only, please refer to the information on the nameplate of the product.

<sup>\*\*</sup>The transformer cabinet is needed additionally when the system is in off-grid mode.

System Manual 11 Appendix

# 11.3 Tightening Torques

To avoid poor contact caused by the loosening of copper cable lugs due to stress, and to prevent heat or even fire due to increased contact resistance, make sure to tighten the screws on the cable lugs at the recommended torques:

Bolt	Torque(N·m)	Bolt	Torque(N·m)
M3	0.7–1	M8	18–23
M4	1.8–2.4	M10	34–40
M5	4–4.8	M12	60–70
M6	7–8	M16	119–140

<sup>\*</sup>Torque values listed in the table are intended for the bolt and nut assembly, and do not apply to riveted nuts or riveted screws, etc. The torque to be adopted should depend on the actual situation.

# 11.4 Quality Assurance

When product faults occur during the warranty period, SUNGROW ENERGY STORAGE TECHNOLOGY CO., LTD.(SUNGROW) will provide free service or replace the product with a new one.

#### **Evidence**

During the warranty period, the customer shall provide the product purchase invoice and date. In addition, the trademark on the product shall be undamaged and legible. Otherwise, SUNGROW has the right to refuse to honor the quality guarantee.

#### Conditions

- · After replacement, unqualified products shall be processed by SUNGROW.
- The customer shall give SUNGROW a reasonable period to repair the faulty device.

### **Exclusion of Liability**

In the following circumstances, SUNGROW has the right to refuse to honor the quality guarantee:

- The free warranty period for the whole machine/components has expired.
- · The device is damaged during transport.
- The device is incorrectly installed, refitted, or used.
- The device operates in harsh conditions beyond those described in this manual.
- The fault or damage is caused by installation, repairs, modification, or disassembly performed by a service provider or personnel not from SUNGROW.
- The fault or damage is caused by the use of non-standard or non-SUNGROW components or software.

<sup>\*\*</sup>Secure the cable at a proper point to reduce the stress on the cable lug.

11 Appendix System Manual

• The installation and use range are beyond stipulations of relevant international standards.

• The damage is caused by unexpected natural factors.

For faulty products in any of above cases, if the customer requests maintenance, paid maintenance service may be provided based on the judgment of SUNGROW.

# 11.5 Contact Information

In case of questions about this product, please contact us. We need the following information to provide you the best assistance:

- · Model of the device
- · Serial number of the device
- · Fault code/name
- · Brief description of the problem

For detailed contact information, please visit: https://en.SUNGROWpower.com/contactUS

