

User Manual

iSolarDesign 4.0

iSolarDesign



All Rights Reserved

All Rights Reserved

No part of this document can be reproduced in any form or by any means without the prior written permission of Sungrow Power Supply Co., Ltd (hereinafter "SUNGROW").

Trademarks

SUNGROW and other SUNGROW trademarks used in this manual are owned by SUNGROW.

Software Licenses

- It is prohibited to use data contained in firmware or software developed by SUNGROW, in part or in full, for commercial purposes by any means.
- It is prohibited to perform reverse engineering, cracking, or any other operations that compromise the original program design of the software developed by SUNGROW.

Contents

All Rights Reserved	
1 About This Manual	1
2 Common Operations	
2.1 Account Registration	
2.2 Login	
2.3 Logout	
2.4 Reset Password	
3 Home	
4 Project List	7
4.1 Card View	
4.2 List View	
5 Project Creation	10
5.1 Quick Design	
5.1.1 Project Information	
5.1.2 Configure PV Modules	12
5.1.3 Electrical Design	13
5.1.4 Generate Report	15
5.2 Standard Design	17
5.2.1 General Information	18
5.2.2 Uploading Map	21
5.2.3 Plant Modeling	22
5.2.4 View Module Layout	25
5.2.5 Electrical Design	27
5.2.5.1 Electrical Configuration	27
5.2.5.2 Inverter and String Configuration	28
5.2.5.3 Cable Loss	31
5.2.6 Electricity Consumption Evaluation	32
5.2.7 Economic Analysis	33
5.2.8 Generate Report	35
5.2.8.1 Export to iSolarCloud	39
6 Custom Module	42
7 Feedback	43
8 Personal Setting	45

9 Messages	. 46
10 Contact Information	. 47

1 About This Manual

Target Group

This manual is applicable to plant designers. The plant designer is required to meet the following requirements:

- Understand the working principle and operation method of the inverter.
- Be familiar with local standards and relevant safety regulations of electrical systems.

Symbol Explanations



NOTE indicates additional information, emphasized contents, or tips that may be helpful, e.g. to help you solve problems or save time.

Requirements

Item	Requirement
Browser	Chrome 60 and above, Safari 10 and above, Firefox 60 and above
Resolution	1920 * 1080 is recommended, and 1366 * 768 is supported

Main Content

This manual is to provide readers with an overview of how to use iSolarDesign.



iSolarDesign V3.1 is taken as an example for illustration in this manual, and figures are for reference only. The actual interface shall prevail.

2 Common Operations

2.1 Account Registration

This section introduces the registration process of an iSolarDesign account.

Prerequisites

The computer can access the network.

Procedure

- **Step 1** Enter https:// design.isolarcloud.com in the address bar of a browser. Press **Enter** to enter the iSolarDesign login interface.
- Step 2 Click in the upper right corner to switch the language.
- Step 3 Click Register to enter the registration interface.
- Step 4 Enter the email address and click Verification Code.
- **Step 5** Enter the verification code received in the mailbox.
 - The verification code is valid in 30 minutes. If it takes more than 30 minutes to register an account, you need to register an account again.
- Step 6 Enter the password twice, and then click Next.
 - Make sure that the password entered twice is the same and consists of at least 8 digits.
- Step 7 Enter First Name and Last Name, select Country/Region and Time Zone, tick I have read and agreed to Terms of Service, and click Register.
 - --End

2.2 Login

Prerequisite

This section introduces the steps for plant designers to log in to the iSolarDesign system.

Prerequisites


- · The account and password are obtained.
- iSolarDesign works normally, and the computer can access the network.

User Manual 2 Common Operations

Procedure

Step 1 Enter https:// design.isolarcloud.com in the address bar of a browser. Press **Enter** to enter the iSolarDesign login interface.

- Step 2 Click in the upper right corner to switch the language.
- **Step 3** Select the server address, enter the email address and password, and click **Login**. The prompt box below may pop up.



Click **Confirm** to enter the 3.1 system, and click **Enter the old system** to enter the home page of the 2.0 system. Tick **Do not remind again** and this box will not pop up later.



Users can select Remember Me as needed to facilitate the next login.

--End

2.3 Logout

This section introduces the steps for plant designers to log out the iSolarDesign system.

Prerequisites

Logged into the iSolarDesign system.

Procedure

Click Logout in the drop-down list of User Account in upper-right corner of the interface.

2.4 Reset Password

Prerequisite

This section introduces how to retrieve the password if the plant designer forgets it.

Prerequisites

- · Already have an account.
- iSolarDesign works normally, and the computer can access the network.

2 Common Operations User Manual

Procedure

Step 1 Enter https:// design.isolarcloud.com in the address bar of a browser. Press **Enter** to enter the iSolarDesign login interface.

Step 2 Click Reset Password to go to the Account and Security interface.



- Step 3 Enter an email address and click Next.
- **Step 4** Click **Send Verification Code**. Enter the verification code received in the mailbox and click **Next**.



Step 5 Enter a new password and click Modify.

The new password must meet the following requirements:




- **a.** The password consists of at least 8 digits.
- **b.** The password contains at least one letter and one number.
- **Step 6** It is prompted that the modification is completed and the system automatically goes back to the login interface.

--End

3 Home

The home page after a successful login is as follows.



N o.	Name	Description
Α	Search bar	Fill in conditions to search for the required projects.
В	Project list	The project that the user has created. See 4 Project Listfor details.
С	Switch between card/list display	The projects can be displayed in Card View or List View . See 4 Project List for details.
D	Create project	Click it to create a new project. See 5 Project Creation for details.
Е	Go to iSolarCloud	Click to go to the iSolarCloud O&M system.
F	Feedback	Make suggestions for iSolarDesign on this interface. See 7 Feedback for details.
G	Help	Check out the User Manual and Help Videos.
Н	Message	Click it to go to the notification interface. See 9 Messages for details.


3 Home User Manual

N o.	Name	Description
I	User account	Display the current user account. Click it to go to the Personal Settings interface or to Exit . See 8 Personal Setting for details.

4 Project List

After a successful login, users will go to the **Item** interface by default. Switching between **Card View** and **List View** is supported.

4.1 Card View



Cards are listed in order of update time and can be filtered by the project status above.

A card contains the following contents:

- Project name: The project name.
- Project scenario: It is divided into residential and commercial plants.
- Type: Standard design or quick Design.
- · Installed power: The total power of the project.
- Address
 The address of the project. Moving the cursor over the address can view the detailed address information.
- Status: The status of the project. The project status includes Draft, Completed,
 Offered, and Others. Click to update the project status.
 - If the project is in **Draft** status, the status cannot be switched.
- Update time: The latest update time of the project.

The following operations can be performed on the card:

4 Project List User Manual


Add to favorites/Remove from favorites: Click to Bookmark the project, and click





Click Favourites in the upper right corner of the interface to display all the projects in the favorites in order of bookmarking time.

- Download: Click to download the overview and layout of the project.
- Delete: Click uto delete the project.
- Create Plant: Click to go to the iSolarCloud Web. Basic Plant Information and Plant Location are filled in automatically. Fill in Owner Information and click Creat Plant.




0

If the project is in **Draft** status, the plant cannot be created.

User Manual 4 Project List

4.2 List View



Projects are listed in order of update time and can be filtered by the project status above.

The following contents are included:

- · Project name: The project name.
- Status: The status of the project. The project status includes Draft, Completed,
 Offered, and Others. Click to update the project status.
 - a

If the project is in **Draft** status, the status cannot be switched.

- Scenarios: Residential or commercial.
- · Type: Standard design or quick Design.
- Installed power: The total power of the project.
- · Update time: The latest update time of the project.
- · Designer: The creator of the project.
- Client: The client name.
- Creation time: The time when the project is created.
- Quantity of device: The number of inverters in the project.
- Street, City, Country, and Project address: The address of the project. Moving the cursor over the address can view the detailed address information.
- Operation: Copy, download, delete, and create plants.
- **User-defined column**: Click in the upper-right corner of the list. Tick the columns to be displayed in the dialog box and click **Confirm**. Click **Reset** to restore the default list.



Project name and Operation are fixed columns and cannot be ticked.

5 Project Creation

Prerequisites


- · Logged into the iSolarDesign system.
- · The computer can access the network.

5.1 Quick Design

Log in as a visitor
 Click Visitor Login on the login page to open the page for quick design.



Log in with an account
 Log in to your iSolarDesign account and click Create Project in the upper right corner of the screen. Then, choose Quick Design > Confirm to go to open the page for quick design.




The work flow of quick design and report output is shown below:



5.1.1 Project Information

Step 1 Fill in General information.



Parameter	Description
Project name*	User-defined name for the project.
Available area (m²)*	Available area of the site where the PV modules are installed.
Project address*	Detailed location of the project.
Latitude (°)*	Auto-filled with the latitude of the project location.
Longitude (°)*	Auto-filled with the longitude of the project location.
Max. ambient (°C)*	Maximum ambient temperature in the place where the project is located. Range: 0 to 60.
Min. ambient (°C)*	Minimum ambient temperature in the place where the project is located. Range:- 40 to 30.
Project scenario*	Select Residential or Commercial as needed.
Grid type*	Select an option based on the actual number of phases and the voltage. For the voltage parameters, refer to the rated AC voltage of the specific inverter model.
Consumption (kWh)	Set the electricity consumption for the project, and select Annual or Monthly .

• Parameters marked with * are required.




To configure a project with microinverters, set the Project scenario to
 Residential, and ensure the selected Grid type is within the range supported
 by the microinverters, such as 1ph 220V.

Step 2 (Optional) Configure Customer information: Enter the Full name and Company.

--End

5.1.2 Configure PV Modules

Complete all project information to configure modules.



Step 1 Select a PV module type: System module or Customize module.

Note: For users who access quick design via Visitor login, only **System module** can be selected.



If system modules do not meet your requirements, you can customize modules.

Select **Customize module**. Click on the right. See 6 Custom Module for details.

Step 2 Select a module manufacturer from the **Manufacturer** drop-down list. Select a module model from the **Model** drop-down list. Click to view module details.

For projects involving microinverters, modules with the following power ranges are recommended:



- S1600S/S800S/S450S: 375 W-570 W modules.
- S1000S: 375 W-650 W modules.
- Step 3 Set the number of modules in Modules.
- Step 4 Select a mounting type. Options include: Flush mount, Tilt, and Dual tilt.

If Tilt is selected, set the Roof azimuth(°) and Roof tilt(°).

If Dual tilt is selected, set the Ridge direction and Relative tilt.

Step 5 If there are multiple PV arrays, click **Add PV array** and refer to steps 2–4 for parameter configuration.




To rename an array, click the 2 icon on the right and click anywhere outside the field to save the settings.

--End

5.1.3 Electrical Design

Electrical design includes electrical configuration and plan configuration.

Step 1 Electrical configuration: Based on site conditions, select Configure microinverter, Configure optimizer, Configure RSD, or Configure battery, and set the Target DC/AC ratio.




- If **Configure microinverter** is selected, other options cannot be selected simultaneously, and the **Target DC/AC ratio** is 1:1 by default.
- If Configure optimizer is selected, set the Optimizer type and Optimizer model according to the project.
- If Configure battery is selected, enter the Total capacity (kWh). The system will recommend an actual capacity based on the total capacity.




Total capacity (kWh) is a required parameter. To ensure energy balance and system stability, the recommended actual capacity may differ from the target capacity. If this does not meet your requirements, you can manually adjust the plan.

Step 2 Electrical design: Based on project conditions, select a system-recommended plan or customize the plan according to actual inventory or preferences.



- Precise DC/AC ratio: Closest match to the target DC/AC ratio.
- · Most economical: Reduce inverter cost and avoid capacity waste.
- · Maximize string use: Maximize PV modules' output power.
- Customize: Click **Customize** for any recommended plan to perform a custom design. You can modify, delete, add, or clear configurations.





- System-recommended plans may vary based on module quantity and inverter power. If the number of modules or inverter power exceeds the upper limit, no recommended plan will be provided, and you can create a custom design.
- If no inverters are compatible with the current configuration, please modify the configuration list: country, grid type, PV configuration, and electrical settings.
- Step 3 Click Confirm to go to Quick design and view the generated plan.
- **Step 4** Adjust the plan content on the generated plan page if needed.





Table 5-1 Operation Instructions

No.	Description
1	Click to open the Electrical design window to edit the overall plan.
2	Click to open the Electrical design window to edit the current inverter.
3	Click to open the device details page.
4	Click to add strings to the current MPPT.
5	Click to delete the current string.
6	Edit the number of modules within the recommended range.


--End

5.1.4 Generate Report

After completing the operations specified in 5.1.1 Project Information, 5.1.2 Configure PV Modules, and 5.1.3 Electrical Design, click **Save and generate report**.



ff microinverters are configured, the BOM also includes microinverter accessories.




5.2 Standard Design

Log in to your iSolarDesign account and click **Create Project** in the upper right corner of the screen. Then, choose **Standard Design > Confirm** to open the page for standard design.



The work flow of standard design and report output is shown below:




Name	Description
Electrical Design	Here you can complete the inverter and string configuration and check the DC- and AC-side cable loss. See 5.2.5 Electrical Design for details.
Electricity Consumptio n Evaluation	It provides forecasts for future electricity use and bills based on current consumption patterns. See 5.2.6 Electricity Consumption Evaluation for details.
Economic Analysis	It provides plant design cost estimation based on the provided project cost details. See 5.2.7 Economic Analysis for details.
Generate Report	It is used to display the project overview and layout. The report can be downloaded to local. See 5.2.8 Generate Report for details.

5.2.1 General Information


Prerequisite

Novice Guide



After clicking **Standard design** and **Confirm**. The **Novice guide** window will pop up. Click **Next** to view the usage of every function. If **Don't show this window again** is selected, the **Novice guide** window will no longer appear.

Step 1 Fill in General information of the project.



Parameter	Description
Project name*	User-defined name for the project.
Project address*	Set the detailed address of the project site. You can roll the wheels on your mouse to zoom in or out and drag the map to aim the site with the location icon.
Latitude (°)*	Auto-filled with the latitude of the project location.
Longitude (°)*	Auto-filled with the longitude of the project location.
Street, City*	The street and city where the project is located, which can be automatically generated after the project address is confirmed.
Postal code	The postal code of the user's address.
Project type*	Select Residential or Commercial as needed.

Parameter	Description
Grid connection type*	Select 100% feed-in, Self-consumption, Zero export, or Off- grid as needed.



Parameters marked with * are required.

Step 2 Fill in Ambient temperature.



Parameter	Description
Min./Max. ambient*	The lowest/highest ambient temperature allowed at the project location. After the project location is set, the minimum/maximum temperature of the project location is automatically filled in. You can also fill in the temperature in the input box.
Irradiation data, Wind speed data, Temperature data	After filling in the address, click Irradiation data , Wind speed data , and Temperature data to see the estimated value of the data for one year.
Irradiance factor	When bifacial modules are used, the light that is reflected to the back of the module can also be absorbed, affecting the photocurrent magnitude and the efficiency of the bifacial module. It is not selected by default. If it is selected, the factor is used to calculate the DC power of the configured inverter. The factor can be defined by users.
Surface reflectivity*	The ratio between solar radiation reflected by Earth's surface and solar radiation incident at the surface. The default value is 0.2. Valid range: 0–1 (excluding 1).




Parameters marked with * are required.

Irradiation data includes direct normal irradiance (DNI), diffuse horizontal irradiance (DHI), and global horizontal irradiance (GHI). GHI is defined as the total solar radiation received on a horizontal surface at ground level, including both direct radiation (DNI) and diffuse radiation (DHI). Formula: GHI = DHI + (cos θ × DNI) (where θ is the solar zenith angle, 0° indicates the sun's rays are vertical to the ground, and 90° indicates the rays are parallel to the ground.)

■ Total Irradiation ■ Direct Irradiance ■ Diffuse Radiation

Step 3 Select the **Grid type**. Click and select an option based on the actual number of phases and the voltage. For the voltage data, refer to the rated AC voltage of the specific model of the inverter.



- **Step 4** (Optional) Fill in the **Customer information**, including the customer's **Full name** and **Company**. You can also add remarks here.
- **Step 5** (Optional) Upload **Attachment**: Select a file or drag it into the attachment box to upload it. The uploaded file can be downloaded to local.
- **Step 6** Click **Next** to finish the project configuration.
 - --End

5.2.2 Uploading Map


Prerequisite

If the roof image taken from the map does not assist the user in drawing the roof, the user can upload the map for adjustment.



Before uploading the map, input the project address to determine the roof image.

Step 1 Click $\stackrel{\frown}{\cap}$ to upload the map. The interface is shown in the figure below.



Step 2 Click Upload image and select a local image.

- **Step 3** After uploading the map, place the two anchor points and on the current map and the uploaded map at the same positions to mark the same coordinates.
- Step 4 Click Confirm.

--End


5.2.3 Plant Modeling

Use **Plant modeling** to draw graphics on the selected pictures, including drawing the edges of the roof and obstacles on the roof, adjusting the scale, removing the background, and switching between 2D/3D, etc. The interface is shown below:



Operation Bar


- ullet : Select. Click to select a line segment or a point and drag and drop it.
 - In 2D view: You can modify the length of a selected line segment, or drag an endpoint or line segment in any direction to adjust the roof area shape.



- In 3D view: You can modify the roof height in three methods:

 Drag a selected line segment up or down to raise or lower the two points on that edge by the same distance.

- Double-click an endpoint and drag it up or down to move the entire roof up or down by the same height. Rooftop obstacles will be automatically recalculated and adjusted based on the new height.
- · Select an endpoint and enter a height value.



- Hold Ctrl button and click to select a single point, a single line segment, single obstacles or to select them in batch in the drawing area.
- 🔯: Draw.
 - Click to draw line segments on the picture. You can view the length and angle of the current line segment in real time in the upper right corner of the interface. Hold Shift to draw horizontal or vertical lines.
 - Select any points on two edge lines to draw the ridge line.
- \square : Use it to create rectangles.
- : Obstacle. Click to draw obstacles on the picture.
 - In 2D view, you can copy, paste, rotate, and move obstacles.
- IT: Scale. Click and select a line segment to modify the length, and the remaining line segments and obstacles will be scaled accordingly.
- Ü : Delete. Click to delete the selected object.
- \square : Background. Click to remove the background or keep the background.
- $\stackrel{\textstyle \smile}{}$: Undo. Click to go back to the previous step.
- C: Redo. Click to resume the undo step.
- Zoom in. Click to enlarge the drawing area.
- Restore. Click to restore to the initial state.

Drawing Area

A 2D view of the project location is displayed by default. If you upload a map in **Project info**, the satellite map is displayed overlapping with the uploaded map according to the positioning points.


Мар

- Orientation, indicating the orientation of the current view. The view automatically adjusts to north up and south down when you click it.
- 2D view. Click to switch to the 3D view.
- 3D view. Click to switch to the 2D view.
- Reset the view. Click to reset the orientation of the view, and place the drawing area in the middle of the picture.
- + : Zoom in. Click it to or scroll the mouse wheel forward to zoom in the view.
- Zoom out. Click it or scroll the mouse wheel back to zoom out the view.
- Rotate the view. After clicking it, press and hold the left mouse button in the drawing area to rotate the view.
- Move horizontally. After clicking it, press and hold the left mouse button to move the view.
- $\widehat{\Psi}$: Reset the height. In the 3D view, click to reset the height of all objects in the drawing area.

5.2.4 View Module Layout


Prerequisite

View Module Layout allows you to deploy PV modules on the roof drawn in 5.2.3 Plant Modeling.



Step 1 Fill in PV panel configuration.


• Set the type of the PV module. You can select **System module** or **Customize module**.



- Click the drop-down list of Manufacturer and select the module manufacturer.
- Click the drop-down list of **PV model** and select the module model. You can click to view the detailed information about the selected module.
- Tick Color.
- Turn on or off Loss analysis as needed. This function is turned off by default. If it is turned on, set the Dust loss, Diode loss, and Backsheet irradiation loss.

Step 2 Fill in PV array.

- Tick Mounting type: Select Flush mount, Tilt, or Dual tilt based on the roof orientation.
 - Select Row offset for Tile;
 - Fill in Azimuth, Tilt angle, Frame size, and Altitude in the Tilt field;
 - Fill in Ridge direction and Relative tilt in the Dual tilt field.
- Set the module layout as Landscape or Portrait. Fill in the Column spacing, Row spacing, and Distance from obstacles/line.
- Step 3 Select the roof. You can then choose Arrange automatically and hold the left mouse button and drag on the roof to create PV modules as you want, or choose Arrange automatically to cover the roof with modules in one click. Click Arrange automatically to fill the roof with modules.





Step 4 Click Configure PV modules, and then click Next.


--End

5.2.5 Electrical Design

Go to "Electrical Design" after finishing PV module arrangement and complete the electrical configuration (DC and AC sides). After this, you can check the wiring distance between different devices and the power loss.

5.2.5.1 Electrical Configuration

Step 1 Electrical configuration: Based on site conditions, select Configure microinverter, Configure optimizer, Configure RSD, or Configure battery, and set the Target DC/AC ratio.



- If Configure optimizer is selected, set the Optimizer type and Optimizer model according to the project.
- If Configure battery is selected, enter the Total capacity (kWh). The system will
 recommend an actual capacity based on the total capacity.



Total capacity (kWh) is a required parameter. To ensure energy balance and system stability, the recommended actual capacity may differ from the target capacity. If this does not meet your requirements, you can manually adjust the plan.

--End

5.2.5.2 Inverter and String Configuration

- Step 1 Click Start design to open the Electrical design window.
- **Step 2** Based on project conditions, select a system-recommended plan or customize the plan according to actual inventory or preferences.
 - Precise DC/AC ratio: Closest match to the target DC/AC ratio.
 - Most economical: Reduce inverter cost and avoid capacity waste.
 - · Maximize string use: Maximize PV modules' output power.
 - Customize: Click **Customize** for any recommended plan to perform a custom design. You can modify, delete, add, or clear configurations.




- System-recommended plans may vary based on module quantity and inverter power. If the number of modules or inverter power exceeds the upper limit, no recommended plan will be provided, and you can create a custom design.
- If no inverters are compatible with the current configuration, please modify the configuration list: country, grid type, PV configuration, and electrical settings.

Step 3 Click **Confirm**. The generated plan will be displayed on the page, and the component connections will be automatically created on the right.



If optimizers/RSDs are configured, short codes will be automatically generated for components on the right after the plan is generated, as shown in the following figure.



Step 4 If needed, you can flexibly adjust the generated plan.



Table 5-2 Operation Instructions

No.	Description
1	Click to open the Electrical design window to edit the plan.

No.	Description
2	Click to clear or delete the current inverter or string.
3	Click to view device details.
4	Click to add a string to the current MPPT.


Step 5 Click the in the toolbar to add other devices to the canvas and check the wiring.




1

You can drag and drop the device to a proper position in the canvas. After adding all inverters and distribution boxes/grid-connection cabinets to the canvas, you can view the power loss information.

Step 6 Click 3D to move the inverter to the wall and view the design in a 3D perspective.



Step 7 Select a cable to check its power loss and other information. Below is an example of an AC cable.




--End

5.2.5.3 Cable Loss

Click Loss Calculation on the left to check the Cable Loss.

- DC: Cable loss from the module to the inverter.
- AC Residential: cable loss from the inverter to the power distribution box; commercial: cable loss from the inverter to the grid-connection point.



You can set the materials and specifications of the cables used on the DC side and AC side. The system will then calculate the **Resistance**, **Power Loss**, **Voltage Drop**, and **Cable Loss Rate** of the cables accordingly.




in the status column indicates an overly high cable loss. In this case, it is suggested to adjust the cable parameters or the position of the inverter.

5.2.6 Electricity Consumption Evaluation


The system can forecast future electricity use and predict electricity bills based on current consumption patterns.

- 1. Set the Annual Consumption (kWh). The system will then calculate the Average Monthly Consumption (kWh).
- 2. **Monthly Consumption** is calculated based on annual consumption and specific consumption scenarios. If the annual consumption data is updated, the monthly consumption will be recalculated accordingly.
- **3.** Set the **Weekday Scenarios** and **Weekend Scenarios**, based on the periods of high electricity demand throughout the day.
- 4. Set the Daily Average Consumption, which is the ratio of weekend consumption to weekday consumption. This allows better consumption allocation between weekends and weekdays.
- **5.** Once the settings are completed, you can view the forecast for monthly and daily electricity use on the right of the page.



5.2.7 Economic Analysis

You can provide the project cost details in **Economic Analysis** to check the estimated plant design cost.



1. Click Settings and set the Basic Economic Parameters.

Parameter	Description	
Currency Unit	Select the common currency in the place where the project is located.	

Parameter	Description		
Discount Rate (%)	It is used to discount expected future earnings back to their present value. When the future earnings are certain, the lower the discount rate, the higher the present value. Changes in the discount rate will result in huge differences in asset valuation results.		
Pay Tax or Not	If Yes is selected, set the Tax Rate (%).		
Tax Rate (%)	National income tax rate.		

2. Set the Initial Installation Cost Type.

Туре	Description
Fixed Price	Enter the price in the input box.
Total Device Cost	Provide the unit price of the device in Device List . The Total Device Cost will then be auto-filled by the system.
Price per watt	Enter the price per watt in PV System Cost . The system will then calculate the total cost automatically.

- 3. Set the PV O&M Cost: The annual operation and maintenance cost of the plant.
- 4. Set the Power Purchase Tariff, Feed-in Tariff, and Self-consumption Rate.
- 5. Click 2 in the action column of the **Device List** to add remarks for the device or set its unit price.
- **6.** To add a new device, click **Add Device**, complete its basic information, and click **Confirm**.



Devices added in **Economic Analysis** can be deleted, while those added in **Electrical Design** cannot be deleted.

7. If any subsidies are granted by the government to the project, click **Add Government**Subsidies to add the relevant information.

Subsidy Type	Description		
Fixed Subsidy	a. Select "Yes" or "No" in Pay Tax or Not.b. Set the Max. Subsidy.		
Based on Installation Cost	a. Select "Yes" or "No" in Pay Tax or Not.		


Subsidy Type	Description		
	b. Set the Subsidy Proportion.c. Set the Max. Subsidy.		
Based on Yield	a. Select "Yes" or "No" in Pay Tax or Not.b. Set the Subsidy Period (Year).c. Set the Subsidy per kWh.		
Based on Installed Capacity	 a. Select "Yes" or "No" in Pay Tax or Not. b. Set the ROI (return on investment). c. Set the Max. Subsidy. 		
Based on Battery Capacity	This option is not available if there is no battery in the device list. a. Select "Yes" or "No" in Pay Tax or Not. b. Set the Subsidy Amount. c. Set the Max. Subsidy.		

5.2.8 Generate Report

After completing the above settings, go to the **Generate report** page.

The report includes the following information:

General information and data overview




· Bill of materials (BOM)

Bill of materials (BOM)					
Туре			Quantity	Price	Cost
String inverter	SUNGROW	SG125CX-P2	1		-
Optimizer	SUNGROW	SP600S(1:1)	425	-	1.000
PV module	Jinko Solar Holding C o., Ltd.	Tiger Mono-facial 375- 395Watt N Type_JKM3 95N-6RL3(-V)	425		

Total EUR


· First year yield & system PR forecast




Revenue



Tariff analysis




· Module layout




Electrical wiring





Social contribution




This page support the following functions:

- Customize report content: Click the Custom icon in the upper left corner to select the information you want.
- Save and download: Click Save and download to save the report locally.
- Export to iSolarCloud: If optimizers/RSDs are configured in the project, you can export the project information and physical layout to iSolarCloud.

5.2.8.1 Export to iSolarCloud


This section describes how to export project information and physical layout to iSolarCloud in scenarios with optimizers/RSDs.

Step 1 Click Export to iSolarCloud in the upper right corner, enter the Owner's email address, and select Synchronize physical layout as needed. Then click Export.




Project information and physical layout can only be exported once.


Step 2 In iSolarCloud, you can view the imported general information and physical layout of the plant. (Note that optimizer/RSD short codes are not shown in the modules of the layout.)



Step 3 On the **Design report** page of iSolarDesign, click **Download layout file** to download the layout file with optimizer/RSD short codes (in Excel format).




Step 4 After entering the device S/Ns in the Excel file, import the layout file into iSolarCloud. The system will generate a physical layout with optimizer/RSD short codes, as shown in the following figure. For details, see *iSolarCloud User Manual*.



1

In addition to the above method, you can also import the information of a project in Completed status from iSolarDesign directly when creating a plant in iSolarCloud. For details, see *iSolarCloud User Manual*.



Cancel

--End


Total 2 20/page ✓ 〈 1 〉 Go to 1

6 Custom Module

You can add a custom module if a module beyond those provided in the system is required.

Log in to the iSolarDesign system, and click **Settings** at the top of the screen to go to the **Customize Module** page.


Add one custom module
 Click Add Module, set the parameters for the module, and click Confirm. The module will then be added.



- · Add custom modules in group
 - 1. Click **Download Template** to download the template file to your local system, and fill in the module information.
 - **2.** Click **Import Template** to import the template that carries the module information. The modules will then be added.
- · Delete one module
 - Click in the Action column to delete the corresponding module.
- Delete modules in group
 Select modules of different models, and click Batch Delete to delete them in group.
- · Edit module information
 - Click in the Action column to edit the information about the corresponding module.
- · View module information
 - Click in the Action column to view the information about the corresponding module.

7 Feedback


Users can submit suggestions on the **Feedback** interface. Click to enter the corresponding interface. Users can only view their own suggestions on this interface.



Add Feedback

Click Make Suggestions to enter the **Make Suggestions** interface, as shown in the following figure.

Make Suggestions



Select **Suggestion Type**, **Functions Involved**, and enter **Description**. Uploading **Attachment** is optional. Click **Submit**.

7 Feedback User Manual



At most 5 attachments can be uploaded, and each file should be no more than 5M. Only PNG and JPG files are supported.

Feedback List



On this interface users can view the status and quantity of suggestions that have been submitted. The status includes **All**, **Pending**, **Processing**, **Adopted**, **Implemented**, and **Closed**.

Click $\dot{\overline{\mathbb{U}}}$ to delete the suggestion, while the administrator's reply will also be deleted.

Feedback Details



Click one of the suggestions to go to the **Details** interface. On this interface users can view the **Suggestion Type**, **Functions Involved**, **Description**, and **Attachment**.

Click Reply to reply to the customer service.



If there is no reply text, the user cannot reply to the customer service.

8 Personal Setting

Personal Setting consists of three functions: Basic Settings, Security Settings, and Data Settings.

Basic Settings




On this interface users can modify the basic information of the account.

Security Settings



On this interface users can modify the email address, delete the account and change the password.

Data Settings



On this interface users can modify the **Temperature Unit**, **Decimal Separator**, **Unit of Length**, and **Language**. Click **Save**.

9 Messages



On this interface users can view system messages. The **All** tab is displayed by default. Users can click **Unread** to view unread messages.

Click Mark All as Read to change the status of all unread messages to read.

10 Contact Information

In case of questions about this product, please contact us.

For detailed contact information, please visit: https://en.sungrowpower.com/contactUS.





Sungrow Power Supply Co., Ltd.